

Philips docking speaker



DS8500



Exceptional sound quality and style

Obsessed with sound

The elegant and chic Philips docking speaker delivers stunning sound from your iPhone/ iPod with PureDigital technology. Enjoy advanced control with proximity sensor and intuitive remote that complements speaker design and finishing.

Exceptional sound performance

- Pure digital processing technology for best sound clarity
- Optimal acoustic volume to match speakers' requirements
- Precisely tuned bass pipes for deep, tight bass reproduction
- Shielding technology to block mobile phone interference

Chic and classy

- · Sensually curved back for elegance and precise sound
- Great look with or without iPod/iPhone docked

Advanced intuitive control

- · Proximity sensor to activate backlit control panel
- · Remote control complements speaker design and finishing
- Free DockStudio app for Internet radio and other cool features



DS8500/12

Specifications

iPhone compatibility

Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

 Compatible with: iPod, iPod mini, iPod with colour display, iPod classic, iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32 GB, iPod 5th generation, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation

iPod/iPhone App

- · App name: DockStudio
- Free download from App store
- Compatibility: iPhone OS 3.0, iPhone OS 4
- Playback: album/track navigation, playback controls
- Sound settings: 5 band equalizer, DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- · Clock: analogue display, digital display
- Alarm: multiple alarms, sleep timer, wake up to music, wake up to sounds of nature, wake up to photos
- 7000+ Internet radio stations
- · Worldwide weather forecast

Audio playback

 Docking playback modes: next and previous track, play and pause

Sound

· Sound system: stereo

BiPod ☐iPhone

- Volume control: up/down
- Output power: 2 x 15 W RMS

Loudspeakers

- Speaker drivers: 2 x 3" full range woofers
- Loudspeaker enhancement: bass reflex speaker system

Connectivity

Aux in

Convenience

· Charging device: iPhone, iPod

Power

• Power supply: 100 - 240 V AC, 50/60 Hz

Accessories

- Cables/Connection: 3.5-mm stereo line-in cable, power cord
- · Remote control
- Others: Quick start guide
- Warranty: Warranty Certificate, Worldwide Guarantee booklet

Dimensions

- Gross weight: 3.1 kg
- Packaging depth: 158 mm
- · Packaging height: 220 mm
- Packaging width: 484 mm
- Weight: 2.3 kg
- · Main unit depth: 139 mm
- Main unit height: 158 mm
- · Main unit width: 421 mm

Highlights

Pure digital sound



Advanced pure digital sound processing technology offers vastly superior sound performance compared to the conventional analogue audio processing technology that is found in docking players that use the analogue audio output from an iPod/iPhone. By collecting the iPod's/iPhone's digital audio output and employing digital processing at each stage of the circuit, a much higher Signal-to-Noise ratio is produced. The result is unsurpassed sound clarity that is in perfect balance.

Optimal acoustic volume

Smart sound design brings you the best bass reproduction possible. The acoustic volume allocated to each midrange driver perfectly matches its acoustic requirements. Low tones come out deep and tight – delivering strong and rich bass.

Curved back for better sound

The clean lines and sensuality of the curved back cover not only looks fabulous – it also creates a more effective structure for acoustics. Carefully designed, the curve increases the stiffness of the speaker cabinet, dramatically reducing internal resonance and resulting in more precise and natural sound reproduction. You get to enjoy both lovely looking speakers and sensational sound.

Proximity sensor



Most top-grade audiophile appliances allow the display to be turned off – for absolute enjoyment of music, and for power to be focused on sound reproduction. With the proximity sensor feature, you can enjoy that too. Walk away and the illuminated functional keys automatically dim. When your hand draws near, the functional keys light up so you can control your music without fuss.



Issue date 2014-03-19

Version: 10.0.8

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 61831 EAN: 87 12581 53611 4

www.philips.com