



Philips AVENT
Digital PhotoFrame

7"

Multimedia 4:3 frame ratio

SPF2207



Re-live the first smile

Philips Avent PhotoFrame

This PhotoFrame is the perfect combination of quality and fun. Colourful frame accessories are also included for personalisation - pink for a girl and blue for a boy. Instantly enjoy the most precious moments of your baby's first years.

Top quality display for amazing viewing experience

- imagen Pro for sharper and vibrant colours
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Supports photos, videos and music
- Customise your frame with Pink or Blue snap-on frames.

Environmentally friendly green design

- Eco-friendly Photoframe
- Auto turning display on/off at pre-set times for power saving

PHILIPS
AVENT

sense and simplicity

Specifications

Picture/Display

- Brightness: 200 cd/m²
- Viewing angle: @ C/R > 10, 120° (H)/100° (V)
- Contrast ratio (typical): 300:1
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- Built-in memory capacity: 512 MB (for 500 HD photos)
- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adapter), MS Pro Duo (via adapter)

Convenience

- Card Reader: Built in (2 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Photo effects: Black and White, Frames, Sepia, Radiant colour
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Grey, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media,

Remaining memory

- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

Accessories

- Included accessories: AC-DC Adapter, Stand, Quick start guide, User Manual

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power supply: 100-240 VAC, 50/60 Hz
- Power consumption: 5 W
- Power mode supported: AC powered

Packaging dimensions

- EAN: 87 12581 47537 6
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 22.5 x 19 x 9 cm
- Gross weight: 1.05 kg
- Net weight: 0.7 kg
- Tare weight: 0.35 kg

Outer Carton

- GTIN: 1 87 12581 47537 3
- Number of consumer packages: 2
- Gross weight: 2.3 kg
- Outer carton (L x W x H): 23.4 x 19 x 19.8 cm
- Net weight: 1.4 kg
- Tare weight: 0.9 kg

Highlights

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo is displayed in 4:3 ratio for the best viewing experience.

Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those times you don't want to spend time copying photos to your PhotoFrame.

Customise with snap-on frames

Two beautifully designed and cheerful frame accessories are included. Pink for girls and blue for boys — sweet dreams guaranteed. Simply snap on.

Eco-friendly PhotoFrame

Philips PhotoFrames are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

imagen Pro

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

SmartPower

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment and saving up to one third of your PhotoFrame energy costs.



Issue date 2010-01-30

Version: 2.2.4

12 NC: 8670 000 51299
EAN: 87 12581 47537 6

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com