



Philips
DVD micro music system

DVD, HDMI ARC
CD, MP3-CD, USB, FM
Karaoke
100W max



MCD5110

Relax with great music and movie

Obsessed with sound

Bring on the best with this Philips DVD micro system—from DVDs, Divx movies and MP3-CDs. Powerful speakers with basspipes and high definition HDMI 1080p upscaling pump up your home entertainment experience.

Enrich your sound experience

- 100W RMS total output power
- Bass Reflex Speakers deliver deep and powerful bass

Enjoy your favorite movies and music

- HDMI 1080p upscales to high definition for sharper pictures
- HDMI ARC to access all the sound from your TV
- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- USB Direct for easy MP3 music playback
- Karaoke for endless singing entertainment at home

Easy to use

- FM digital tuning to preset up to 20 stations

PHILIPS

Highlights

HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

HDMI ARC

HDMI ARC to access all the sound from your TV

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Karaoke for endless singing



Karaoke for endless singing entertainment at home

Play DVD, VCD, MP3-CD, CD(RW) & Pict



The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

Bass Reflex Speakers

A chamber behind the speaker driver that channels air to acoustically tuned vents built into the speaker give the bass notes a more punchy, realistic sound.

Specifications

Sound

- Sound Enhancement: Digital Sound Control
- Sound System: Dolby Digital
- Maximum output power (RMS): 100W

Loudspeakers

- Speaker drivers: 4.5" woofer
- Main Speaker: 2 way
- Loudspeaker types: Mylar tweeter

Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 2
- Video Enhancement: Video Upscaling

Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Stop

Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/+RW

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store

- Station presets: 20
- Antenna: FM antenna
- RDS: Program Type, Station Name

Connectivity

- HDMI 1: HDMI (Audio Return Channel)
- Video Output - Analog: Composite CVBS (yellow cinch)
- Audio Connections: Analogue Audio In (L/R)
- USB: USB host
- Microphone: Microphone socket
- Rear Connections: AUX in
- Subwoofer out: 1

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Indications: DIM mode

Accessories

- Included accessories: Composite video cable (Y), AC Power Cord
- User Manual: Multi-languages
- Remote control

Dimensions

- Main unit depth: 243 mm
- Main unit height: 120 mm
- Main unit width: 200 mm
- Main speaker dimensions (W x D): 160 x 206 mm
- Main speaker height: 243 mm
- Packaging depth: 265 mm
- Packaging height: 465 mm
- Packaging width: 396 mm
- Net weight: 5.8 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2016-12-14

Version: 2.0.8

12 NC: 8670 001 02474
EAN: 08 71258 16857 44

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com