

PHILIPS

USB power bank

30,000 mAh

USB A and USB C charging ports

QC 3.0 and PD

White

DLP1930CW



Powerful power bank with a portable back-up power pack

Have power wherever and whenever you need it. Large 30,000 mAh capacity for up to more than 1 full charge. 3 USB ports with USB-A and USB-C. Fast charge your device with USB-C PD 3.0 Max 20 W or a USB-A port with QC 3.0 Max 18 W output.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- Quick Charge technology to optimise charging speed
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously

Portable power

- Recharge your devices multiple times on the go
- Works anywhere - great when you're not near a power source
- Fast charge with USB-C PD 3.0 20 W or USB-A with QC 3.0 18 W

Confirm operation at a glance

- LCD display for power indication

Highlights

LCD display for power status

LCD display for power indication

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.



Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Fast charge USB-C or USB-A

Fast charge your device with USB-C PD 3.0 Max 20 W or a USB-A port with QC 3.0 Max 18 W output

Specifications

Accessories

User Manual: User Manual

Cables: USB-C cable

Power

Output: USB & Type-C 5 V/3 A

Power input: USB C/Micro USB 5 V/2 A

Battery Capacity: 30,000 mAh 111 Wh

Outer Carton

Number of consumer packages: 21

Outer carton (L x W x H): 39 x 35 x 23 cm

Outer carton (L x W x H): 15.4 x 13.8 x 9.1 inch

Gross weight: 15.96 kg

Net weight: 12.978 kg

Tare weight: 2.982 kg

Gross weight: 35.185 lb

Net weight: 28.611 lb

Tare weight: 6.574 lb

GTIN: 1 48 95229 13428 4

Packaging dimensions

Number of products included: 1

Packaging dimensions (W x H x D):

9.5 x 19.5 x 5 cm

Packaging dimensions (W x H x D):

3.7 x 7.7 x 2.0 inch

Gross weight: 0.698 kg

Net weight: 0.618 kg

Tare weight: 0.08 kg

Gross weight: 1.539 lb

Net weight: 1.362 lb

Tare weight: 0.176 lb

EAN: 48 95229 13428 7

Product dimensions

Product dimensions (W x H x D):

7.2 x 14.2 x 4.09 cm

Product dimensions (W x H x D):

2.8 x 5.6 x 1.6 inch

Weight: 0.618 kg

Weight: 1.362 lb

Inner Carton

Number of consumer packages: 7

Inner carton (L x W x H): 36.5 x 11 x 20.5 cm

Inner carton (L x W x H): 14.4 x 4.3 x 8.1 inch

GTIN: 2 48 95229 13428 1

