

Philips Clock Radio

Time projection



AJ5030



# Wake up and beam

# with a time projection

Enjoy the convenience of time shone onto any surface you like. Sharpen the image or flip it, so it is always clear and readable on a wall or ceiling. This clock also automatically sets the time and offers melody, radio or buzzer as alarm options.

# Time projection with a style

- Flexible projection angle for easy viewing anywhere
- · Adjustable focus for sharpest time projection
- Flip control to reverse projected image

# Start the day your way

- Digital tuning with preset stations for extra convenience
- · Dual alarm to wake you and your partner at different times
- Gentle wake for a pleasant waking experience
- Repeat alarm for additional snooze
- Wake up to a melody, buzzer or radio

# Easy to use

- Plug and set the time automatically
- Time and alarm backup to wake up on time even with power cut
- · Adjustable display brightness for comfortable viewing
- Sleep timer helps you to drop off to your favourite music



# Highlights

# Flexible projection angle

Have things your way with a clock that shines the time anywhere you want, thanks to a projection tube that has a flexible casting angle. The tube can be adjusted horizontally and vertically, with fine adjustment controls, so you can get the time image exactly where you want it — on the wall, ceiling or piece of furniture. It lets you check the time without even having to turn your head, and it simply looks great.

#### **Adjustable focus**

Get projected time images that are always sharp with an easy-to-use focus control. You can adjust the focus control to maintain a clear, projected image range from 1 to 2.5 m. Enjoy clean and sharp projected images, and always have a clear view of time.

#### Flip control

This clock radio projects the time onto the wall or ceiling for convenient viewing. With the Flip control feature, you can immediately rotate the projected time 180 degrees for easier viewing from anywhere in the room.

# Plug and set

Take the clock out of its box, plug it in and the time is already set for you - automatically. The intelligent clock reads pre-programmed data and sets the correct time according to the default time zone. If you are living outside the default time zone, all you have to do is press the Time zone button and the clock will reset the time. No more reading manuals, no more fiddling with buttons.

### Time and alarm backup

When there is a power failure, this intelligent clock will still maintain its reliable time and your settings. The scheduled alarm remains active even when its display is off - all thanks to a pre-installed battery. When the power comes back on, there is no need to adjust the clock or reinstate settings. More amazingly, even if power supply is not restored, the battery provides enough energy for the buzzer to go off at the alarm time you have set - making sure you never wake up late.

# Wake up to a melody or buzzer



Have a great start to each day with your choice of wake up call. Have a buzzer or melody wake you or opt for your favourite radio station to rouse you from your slumber.

### Gentle wake



Start your day the right way by waking up gently to a gradually increasing alarm volume.

Normal alarm sounds with a pre-set volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favourite music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

#### Sleep timer



Sleep timer lets you decide how long you want to listen to music, or a radio station of your choice, before falling asleep. Simply set a time limit (up to 1 hour) and choose a radio station to listen to while you drift off to sleep. The Philips radio set will continue to play for the selected duration and then automatically switch to a power-efficient and silent stand-by mode. Sleep Timer lets you fall asleep to your favourite radio DJ without counting sheep or worrying about wasting power









# Specifications

#### **Convenience**

- Alarms: 24-hour alarm reset, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze), Sleep timer
- Clock/Version: Digital
- Display Type: 4-digit displayClock Enhancements: Backup Clock

# Tuner/Reception/Transmission

• Tuner Bands: FM

# Sound

- Sound System: Mono • Volume Control: rotary
- Output power (RMS): 600 mW

#### **Accessories**

• Included accessories: AC Power Cord, User Manual, Warranty certificate

#### **Dimensions**

- Packaging type: D-box
- Product dimensions (W x H x D): 136 x 66 x 136 mm
- Gross weight: 0.6 kg
- Packaging dimensions (W x H x D): 215 x 159 x 94 mm

# **Power**

- Number of batteries: 1
- Backup battery: CR2032 (included)
  Power supply: 110-240V



Issue date 2016-02-07

© 2016 Koninklijke Philips N.V. All Rights reserved.

Version: 3.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 77519 EAN: 87 12581 60611 4

www.philips.com