

Philips
DVD Mini Hi-Fi System



FWD876

Ideal TV pal with superb sound

Ultimate power with 5.1 Surround Sound

Your TV has met its match with the sleek FWD876, featuring the ultimate in sound performance: 5.1 Surround Sound, MAX Sound for instant power boost and 3-step DBB for superb bass. Also, enjoy photos and music directly from your USB devices.

Enrich your movie experience

- DivX playback for high compression video
- Digital Surround DTS for dynamic home surround sound
- Dolby Pro Logic II for surround sound from stereo sources
- Progressive Scan component video for optimized image quality

Powerful sound you can hear and feel

- Total power 600W RMS/ 8000W PMPO
- MAX Sound for instant power boost
- Digital Sound Control for optimized music style settings
- 3-step Dynamic Bass Boost for deep bass experience

Continuous enjoyment of your favorite music

- USB Direct for music and photo playback
- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Digital tuning with 40 preset stations for extra convenience
- Logic tape deck

PHILIPS
sense and simplicity

Highlights

DivX playback

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

Dolby Pro Logic II Surround

Dolby Pro Logic II is an advanced matrix decoder that derives five channels of surround sound, including two full-range surround channels, from any stereo source.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Total 600W RMS/ 8000W PMPO

Total power 600W RMS/ 8000W PMPO

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Play DVD, MP3, WMA, Picture CD

The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

40-preset digital tuning

Digital radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.



Specifications

Sound

- Output Power: 8000W PMPO
- Total Sound Power (RMS): 600 W
- Sound Enhancement: MAX Sound, Dynamic Bass Boost 3 steps, Virtual Ambience Control, Digital Sound Control
- Sound System: DTS, Dolby Digital Surround Sound, Dolby Prologic II

Loudspeakers

- Main Speaker: 2 x 5.25" woofer, 3" woofer, 2" tweeter, 3 way, Bass Reflex Speaker System
- Number of Loudspeakers: 5.1
- Subwoofer type: Active

Video Playback

- Loader Type: Motorised
- Number of Discs: 1
- Playback Media: DVD, DivX, DVD+R/+RW, DVD-R/-RW, SVCD, Video CD, Picture CD
- Disc Playback Modes: Disc Menu, OSD, Fast Forward, Fast Backward, Slow Forward, Slow Backward, Search forward/reverse, Resume Playback from Stop, A-B Repeat, Chapter repeat, Repeat, Angle, Zoom
- Video Enhancement: Progressive Scan
- DVD Region.: 3
- USB Direct Playback: JPEG, MPEG, AVI

Still Picture Playback

- Playback Media: Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow, Flip photos, Rotate, Zoom

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- ID3-tag support
- Disc Playback Modes: Repeat/one/all/program, 99-Track Programmable
- USB Direct Modes: Play/Pause, Previous/Next, Fast Backward/Fast Forward, Stop, Repeat, Shuffle, Program Play
- Cassette Deck Technology: Full Logical
- Number of decks: 1
- Cassette Playback Modes: Fast Wind/Rewind, Automatic Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start

Recording, Automatic Recording Level

Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Station presets: 40
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

Connectivity

- Headphone: 3.5 mm
- Microphone: Dual Microphone sockets
- USB: USB host
- Other connections: ComponentVideo out, Progressive, Composite video (CVBS) out, S-Video out, DIN connection, Digital output (cinch), Line out, Subwoofer out, FM Antenna, MW Antenna
- Aux in: Line in

Convenience

- Alarms: CD Alarm, Radio Alarm, Tape alarm, Sleep timer
- Display Type: FTD
- Clock: On main display
- Karaoke: Echo control, Key control, MIC volume
- OSD Languages: English, French, Portuguese, Russian, Spanish, Thai, Traditional Chinese

Accessories

- Included accessories: YPbPr component video cable, Composite video cable (Y), Video Cable, DIN Cable, AC Power Cord, Batteries for remote control, Quick start guide, FM/MW Antenna
- Remote control: 45-key
- User Manual: English, Traditional Chinese, Russian
- Standard Package Includes: International Guarantee

Dimensions

- Set dimensions (W x H x D): 190.6 x 411.8 x 315.2 mm
- Main speaker dimensions (W x H x D): 165.2 x 554 x 283.2 mm
- Packaging dimensions (W x H x D): 565 x 627 x 663 mm
- Weight incl. Packaging: 35.7 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2011-03-30

Version: 3.0.7

12 NC: 9073 100 13607
EAN: 87 10895 99301 2

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com