

Philips  
Portable Speaker System



SBA230



## Pure sound quality 2 x 2W

### Powerful XSL Acoustics

Take this portable speaker system with you anywhere you go to share high quality powerful sound with your friend from any portable device. The speakers fit easily into your pocket or bag, and are protected by a handy pouch.

#### Powerful Sound

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost electronically enhances the low tones

#### Take your music with you

- Small and lightweight for carrying in your pocket or bag
- Carrying pouch to protect your speakers when not in use
- Universal use with all portable entertainment equipment

#### Always ready to go

- Cable neatly stored when not in use

**PHILIPS**  
sense and simplicity

# Specifications

## Sound

- Frequency response: 100 - 20 000 Hz
- Impedance: 4 ohm
- RMS Power rating: 2x2W (4W)
- Sensitivity: 80 dB
- Sound Enhancement: Dynamic Bass Boost
- Speaker diameter: 40 mm
- Type: Neodymium

## Connectivity

- Cable length: 0.4 m
- Connector: 3.5 mm stereo
- Finishing of connector: Nickel plated

## Convenience

- Bass level control
- Operating time: 6 hours
- Power on indication
- Volume control

## Accessories

- Pouch

## Power

- Adaptor type: 9V 500mA
- Battery type: AAA, LR03
- Battery voltage: 1.5 V
- Number of batteries: 6

## Packaging dimensions

- Packaging dimensions (W x H x D): 18.2 x 21.8 x 6 cm
- Gross weight: 0.411 kg
- Nett weight: 0.276 kg
- Tare weight: 0.135 kg
- EAN: 87 12581 45815 7
- Number of products included: 1
- Packaging type: Carton

## Outer Carton

- Gross weight: 3.13 kg
- Outer carton (L x W x H): 40.8 x 20.3 x 22.8 cm
- Nett weight: 1.656 kg
- Tare weight: 1.474 kg
- EAN: 87 12581 45816 4
- Number of consumer packagings: 6

## Inner Carton

- Gross weight: 0.928 kg
- Inner carton (L x W x H): 19 x 13 x 20.3 cm
- Nett weight: 0.552 kg
- Tare weight: 0.376 kg
- EAN: 87 12581 45817 1
- Number of consumer packagings: 2

# Highlights

## XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

## DBB Dynamic Bass Boost

Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

## Compact and lightweight

Small and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere.

## Carrying pouch

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

## For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

## Speaker cable management

With it's unique design, cable storage is no longer an issues. Simply pack and go.



Issue date 2013-01-31

Version: 1.2.2

12 NC: 8670 000 48617  
EAN: 87 12581 45815 7

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)