

Philips Streamium
Wireless Music Centre



Streamium



WAC3500D

Stream, dock and play all your music on one system

For true convenience, the all-in-one WAC3500D Wireless Music Centre with 80 GB hard disk lets you stream music from your PC, dock your iPod, plug and play from USB devices and enjoy HDD playback - all in superb sound.

All your music on one wireless system

- Stream and copy music from PC with drag 'n drop
- 80 GB hard disk to store and play back up to 1500 CDs
- Dock and charge your iPod and enjoy music in quality sound
- Plug and play directly from your USB flash memory device

Easy navigation and control

- Alphanumeric search with remote control
- Search by artist, album, track or genre on large display
- Rip CDs with Gracenote automatic song information search

Quality sound performance

- 2 x 40 W RMS Hi-Fi sound
- Class 'D' digital amplifier for quality sound performance

Expandable

- Extend your system by adding up to 5 Wi-Fi Stations



PHILIPS
sense and simplicity

Highlights

80 GB hard disk/1500 CDs

The 80 GB hard disk provides a very large capacity for you to store your digital audio files, easily holding up to 1500 audio CDs. Space saving, smart audio collection management, easy access and all in one place.

Class 'D' Amplifier

The Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output

delivers all the advantages of digital audio, including improved sound quality. In addition, the Class 'D' Digital Amplifier has over 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.



Specifications

Sound

- Equalizer settings: Classic, Jazz, Pop, Rock, Techno, Neutral
- Sound Enhancement: Dynamic Bass Boost 3 steps, Equalizer, Incredible Surround, Treble and Bass Control, Class "D" Digital Amplifier, Smart equalizer
- Music Power: 160 W
- Volume Control: Volume Control up/down
- Output Power: 2 x 40 W (RMS)

Loudspeakers

- Built-in speakers: 2
- Main Speaker: 2-way, 5" woofer

Audio Playback

- Compression format: MP3, WMA
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Next/Previous Track Search, Fast Forward/Reverse, Repeat Play
- ID3-tag support
- Loader Type: Tray
- MP3 bit rates: 32–320 kbps and VBR
- WMA bit rates: 16–128 kbps
- Hard Disk Playback Mode: Album, Genre, Playlist, All tracks, Same Artist, Same Genre
- Hard Disk Streaming Mode: Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"
- Sample frequencies: 8–48 kHz (MP3), 16–48 kHz (WMA)
- PC Link playback mode: MP3 streaming via network, Wi-Fi wireless connection
- USB Direct Modes: Play/Pause, Previous/Next, Stop
- Internet Radio: Live365, Radioio, Bluebeat

Audio Recording

- Recording Media: HDD
- Recording speed: 1 x, 4 x
- Audio file format: MP3

Storage Media

- Hard Disk Capacity: 80 GB

Tuner/Reception/Transmission

- Tuner Bands: FM

- Auto digital tuning
- Auto store
- Number of Pre-set Channels: 60

Connectivity

- Audio cinch in: Analogue AUX (Centre)
- Other connections: Ethernet
- Headphones: 3.5 mm
- Antenna: FM Dipole
- Wireless connections: Wireless LAN (802.11 g)
- Power: 220 V–240V/50 Hz
- Wireless Universal Plug and Play: Enabled
- LAN wired: Ethernet (RJ 45) 1 x

Convenience

- Display Type: LCD
- Backlight
- Backlight colour: White
- On-Screen Display languages: English, Dutch, French, German, Italian, Spanish
- Digital Content Management: WADM software included
- Eco Power Standby: 1 watt
- Headphone jack
- Clock: On main display

Accessories

- Cables: Ethernet Cable
- CD-ROM: PMM, WADM
- Remote control: 1-way Remote
- Batteries: 2 x AAA
- Warranty Card: Warranty Card
- Docking Station: DC1050 iPod Dock and cables
- Included accessories: AC Power Cord, FM antenna
- Quick start guide: English, French, German, Dutch, Italian, Spanish
- User Manual: English, French, German, Dutch, Italian, Spanish

Dimensions

- Master carton weight: 11.5 kg
- Carton dimensions (WxDxH): 368 mm x 546 mm x 312 mm
- Product dimensions (WxDxH): 505 mm x 280 mm x 220 mm
- Set weight: 9.00 kg



Issue date 2011-07-01

Version: 4.1.15

12 NC: 8670 000 33141
EAN: 87 12581 35770 2

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com