

When alarm sounds, press **SNOOZE**.
↳ The alarm snoozes and repeats ringing nine minutes later.

1 Press **AL1/AL2** to view alarm settings.
2 Press **AL1/AL2** again to activate or deactivate the alarm timer.
↳ If the alarm timer is activated, **[AL1]** or **[AL2]** is displayed.
• To stop the ringing alarm, press the corresponding **AL1** or **AL2**.

Note:
When alarm sounds, volume increases gradually. You cannot adjust the alarm volume manually.

Note:
Make sure that you have set the clock correctly.

AUX

1 SOURCE
2 AUDIO IN

Press **SLEEP** repeatedly to select a period (in minutes). After the set period, the product switches to standby mode automatically.
• To deactivate the sleep timer, press **SLEEP** repeatedly until **[OFF]** (off) is displayed.

Charge your mobile devices

1 Connect the clock radio with your mobile device.
• For **Android-powered mobile device with a micro USB socket**: use the supplied cable to connect the product with the mobile device.
• For **Apple device with a lightning or 30-pin connector**: use the charging cable of the Apple device (not supplied) to connect the product with the mobile device.

2 Connect the clock radio to AC power.
↳ The mobile device begins to charge.

Specifications

Amplifier	
Total Output Power	2W
Tuner (FM)	
Tuning Range	87.5-108 MHz
Tuning Grid	100 kHz
Sensitivity	
- Mono, 26 dB S/N Ratio	<22 dBf
- Stereo, 46 dB S/N Ratio	<51.5 dBf
Total Harmonic Distortion	<3%
Signal to Noise Ratio	>50 dB
Bluetooth	
Bluetooth version	V3.0
Supported profiles	HFP, A2DP, AVRCP
Range	10 m (Free space)
General information	
AC power (power adapter)	Brand name: Philips Model: CS12F055180FAF; Input: 100-240V~, 50/60 Hz, 500 mA; Output: 5.5V \approx 1.8 A
USB Port	5V \approx 1 A
Operation Power Consumption	10 W
Standby Power Consumption	<1 W
Dimensions:	
- Main Unit (W x H x D)	112 x 101 x 125 mm
Weight:	
- Main Unit	0.5 kg

PHILIPS

Warranty Against Defects

In this warranty:
We means WOOX Innovations Singapore Pte Ltd ARBN 165 105 975, and our contact details are set out at the end of this warranty;
You means the purchaser or the original end-user of the Goods;
Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or New Zealand; and
Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand.

If you require assistance with the operation of the product, its features or specifications please call the Philips Consumer Care Centre on 1300 850 633 in Australia or 0800 639 953 in New Zealand.

Australia: If you are taken to have been supplied with our goods as a "Consumer" for the purposes of the Australian Consumer Law then : Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This is not a complete statement of your legal rights as a consumer.

New Zealand: Our Goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

Additional Warranty: In addition to the rights and remedies that you may have under the Australian Consumer Law, Consumer Guarantees Act of New Zealand or any other applicable law, we provide the following warranty against defects: **(Additional Warranty).**

- If, during the first **12 months** from their date of purchase from the Supplier (**Warranty Period**), the Goods prove defective by reason of improper workmanship or materials and none of your statutory rights or remedies apply, we will repair or replace the Goods without charge.
- We do not have to repair or replace the Goods under this Additional Warranty if the Goods have been used for a commercial purpose; misused, improperly or inappropriately installed, operated or repaired; abused; damaged; or not maintained in accordance with the manufacturer's instructions.
- Even when we do not have to repair or replace the Goods, we may decide to do so anyway. In some cases, we may decide to substitute the Goods with a similar alternative product of our choosing. All such decisions are at our absolute discretion.
- All goods that are repaired, replaced or substituted under this Additional Warranty continue to receive the benefit of this Additional Warranty for the time remaining on the original Warranty Period.
- This Additional Warranty is limited to repair, replacement or substitution only. As far as the law permits, we will not be liable for any loss or damage caused to property or persons arising from any cause whatsoever.
- In order to claim under this Additional Warranty you must telephone us on 1300 850 633 in Australia or 0800 639 953 in New Zealand within the Warranty Period. You will be asked for details of the Goods, a description of the defect and your personal details. Upon accepting your claim, we shall assist you with either returning the Goods to the Supplier for replacement or a Philips Authorised Service Centre in Australia or New Zealand for your Goods to be repaired. We may require that you return the Goods for repair, replacement or substitution.

* All returned Goods must be accompanied by satisfactory proof of purchase which clearly indicates the name and address of the Supplier, the date and place of purchase and identifies product. It is best to provide a legible and unmodified receipt or sales invoice.
 * You must bear any expense for return of the Goods or otherwise associated with making your claim under this Additional Warranty.

7. This warranty is only valid and enforceable in Australia and New Zealand.
 Contact us for further details.

In Australia contact
 Consumer Care: 1300 850 633
 E-mail: le.anz@philips.com
 Website: www.philips.com/support
 65 Epping Rd, North Ryde, NSW 2113

In New Zealand contact
 Consumer Care: 0800 639 953
 Email: le.anz@philips.com
 Website: www.philips.com/support

© 2013 WOOX Innovations Limited. All rights reserved.
 This product was brought to the market by WOOX Innovations Limited or one of its affiliates, further referred to in this document as WOOX Innovations, and is the manufacturer of the product.
 WOOX Innovations is the warrantor in relation to the product with which this booklet was packaged. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V."