

Philips
Mini Hi-Fi System

MP3/WMA

FWM372



Enjoy digital music via USB Direct playback

Fulfil all your music needs with this MP3/WMA Mini Hi-Fi System which features Philips' MAX Sound for instant powerful boost. Enjoy your digit music in a high power system via the USB Direct.

Powerful sound you can hear and feel

- 3-way Speaker System with MAX bass port
- 2x60W RMS/2x120W music power

Longer listening, greater enjoyment

- Enjoy MP3/WMA music directly from your portable USB devices
- 60 hours of WMA-CD or 30 hours of MP3-CD music playback
- 3-disc changer for WMA/MP3-CD music playback
- Dual logic tape deck with auto replay

Personalised sound settings

- MAX Sound for instant power boost
- Dynamic Bass Boost for deep and dramatic bass
- Digital Sound Control for optimized music style settings
- Virtual Ambience Control provides simulated sound settings

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x120W music
- **Sound Enhancement:** MAX Sound, Dynamic Bass Boost 3 steps, Digital Sound Control 4 modes, Virtual Ambience Control

Loudspeakers

- **Main Speaker:** 3 way, Bass Reflex Speaker System, 5.25" woofer, 2" tweeter, Piezo
- **Number of Loudspeakers:** 2

Audio Playback

- **Loader Type:** 3 CD Carousel
- **Number of Discs:** 3
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- ID3-tag support
- **Compression format:** MP3, WMA
- **Disc Playback Modes:** 99-Track Programmable, Repeat/one/disk/program, Shuffle Play
- **Cassette Deck Technology:** Full Logical
- **Number of decks:** 2
- **USB Direct Modes:** Play/Pause, Previous/Next, Fast Backward/Fast Forward, Stop, Repeat, Shuffle, Program Play

Audio Recording

- **Tape Recording Enhancement:** Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Auto digital tuning
- **Tuner Bands:** FM, MW, AM
- **RDS:** News, Program Type, Radio Text, RDS Clock Set, Station Name

- **Station presets:** 40
- **Tuner Enhancements:** Auto Store, Easy Set (Plug & Play)

Connectivity

- **USB:** USB host
- **Aux in:** Line in
- **Headphone:** 3.5 mm
- **Other connections:** FM Antenna, MW Antenna

Convenience

- **Eco Power Standby:** 1 watt
- **Alarms:** CD Alarm, Radio Alarm, Sleep timer
- **Clock:** On main display
- **Display Type:** FTD
- **Indications:** DIM mode

Accessories

- **Included Accessories:** AC Power Cord, FM/MW Antenna, Quick Use Guide, User Manual, Guarantee booklet
- **Remote control:** 32-key with 2xAA batteries

Dimensions

- **Set dimensions (W x H x D):** 265 x 310 x 367 mm
- **Main speaker dimensions (W x H x D):** 248 x 310 x 195 mm
- **Packaging dimensions (W x H x D):** 611 x 411 x 440 mm
- **Weight incl. Packaging:** 15.6 kg

Power

- **Power supply:** 200-240 V, 50Hz
- **Standby power consumption:** 1 W

Product highlights

3-way spk sys with MAX port

2x60W RMS/2x120W music power

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

60 hours of WMA-MP3-CD music

3-disc changer for WMA/MP3-CD

Dual logic tape deck

MAX Sound

MAX Sound technology produces an instant boost in bass, maximising volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Virtual Ambience Control

Virtual Ambience Control (VAC) creates a virtual sound environment which digitally mimics the acoustic characteristic of special rooms or environments such as concert halls, the cinema, arcades, discos, etc. By realistically recreating the sound ambience of these different settings, VAC will dramatically enhance your enjoyment of your favourite music.



Issue date 2007-12-06

Version: 2.0

12 NC: 9073 100 13052
EAN: 87 10895 95270 5

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Music with Digital Right Management not supported.