

Philips
Classic micro sound
system

Dock for iPod

DC156



Obsessed with sound

Relax to great music

Experience your iPod music in superb sound quality with the DC156. Just dock your iPod and enjoy music the way you like it. DC156 also offers fast and precise tuning via its 40 preset stations.

Enjoy your music from multiple sources

- Play and charge your iPod simultaneously
- Play CD, CD-R and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings

Easy to use

- Single remote control for the system and iPod
- Wake-up and sleep timer functions

PHILIPS

Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Fast Forward/Reverse, Next/Previous Track Search, Shuffle Play
- Loader Type: Top
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

Sound

- Output Power: Total 15 W RMS
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

- Headphones: 3.5 mm
- Other connections: FM fixed pigtail antenna, AM Antenna
- Audio Connections: 3.5 mm Line in

Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- Backlight

Accessories

- Included accessories: FM/MW Antenna, World Wide Warranty leaflet, IFU/User Manual
- Remote control: 24-key remote control
- Cradle: Adapters for iPod
- Quick start guide: English
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 326 x 270 mm
- Weight incl. Packaging: 4.83 kg

Power

- Power supply: 220-240 V, 50 Hz

iPod compatibility

- Compatible with: iPod mini, iPod nano, iPod with colour display, iPod 5th Generation, iPod classic

Highlights

Play and charge your iPod

Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2017-04-04

Version: 1.0.4

12 NC: 8670 000 71869
EAN: 87 12581 58196 1

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com