

Philips
Portable Speaker System

SBA160



Powerful stereo sound stage

for your Nokia phone

Enjoy powerful and wide stereo sound from your Nokia phone with 2.5 mm plug. These speakers pack a lot of punch with a highly efficient, interference-free digital amplifier and come with an integrated phone cradle.

Powerful Sound

- Class 'D' digital amplifier for quality sound performance
- Integrated FM Antenna

For superb music pleasure

- Bass pipe emphasises low tones for a clear, realistic sound
- Powerful speaker drivers for ultra-realistic sound
- Wide stereo sound stage when speakers are placed apart.

Take your music with you

- Lightweight, portable design for music enjoyment any time

Always ready to go

- Battery or AC power option for music enjoyment anywhere

Share your music anywhere

- Works with your phone and MP3 players
- Made for Nokia XpressMusic

PHILIPS
sense and simplicity

Specifications

Sound

- **Frequency response:** 150 - 20000 Hz
- **Impedance:** 8 Ohm
- **RMS Power rating:** 2 x 0.6 W

Connectivity

- **Connector:** 2.5 mm Nokia connector. Adapter for 3.5 mm audio sources included.

Convenience

- **Operating time:** up to 25 hours

Accessories

- AC/DC adapter
- **Phone holder:** Cradle for Nokia 5200/5300 XpressMusic, Universal cradle for other Nokia phones and MP3 players included.

Electricity

- **Battery type:** AAA, LR03
- **Adapter type:** 6 V 500 mA
- **Battery voltage:** 1.5 V
- **Number of batteries:** 4

Packaging dimensions

- **EAN:** 87 12581 38369 5
- **Number of products included:** 1
- **Packaging type:** Box
- **Packaging dimensions (W x H x D):** 21.8 x 22.3 x 11.5 cm
- **Gross weight:** 0.889 kg
- **Net weight:** 0.654 kg
- **Tare weight:** 0.235 kg

Inner Box

- **EAN:** 87 12581 38371 8
- **Number of consumer packages:** 2
- **Inner carton (L x W x H):** 24.2 x 22.6 x 20.3 cm
- **Gross weight:** 1.956 kg
- **Net weight:** 1.308 kg
- **Tare weight:** 0.648 kg

Outer Box

- **EAN:** 87 12581 38370 1
- **Number of consumer packages:** 6
- **Outer carton (L x W x H):** 69.6 x 25.7 x 22.3 cm
- **Gross weight:** 5.996 kg
- **Net weight:** 3.924 kg
- **Tare weight:** 2.072 kg

Product highlights

For music enjoyment anywhere

The options of battery and AC power allow the most flexibility with your sound system. You can carry it and enjoy music anywhere you go.

Class 'D' Amplifier

The Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, the Class 'D' Digital Amplifier has over 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Wide stereo sound stage

These portable speakers create a natural stereo sound stage when they are placed apart, giving the impression that each musical instrument occupies a different physical space. The effect is more realistic and more enjoyable.

Integrated FM Antenna

For your phone's FM radio to work properly it usually needs an external antenna. This Philips product includes an FM antenna so you get quality sound from your phone's built-in radio.

Works with phones and MP3

Enjoy music from your mobile phone or your MP3 player! Connect your speaker to your mobile phone or MP3 player with the included adapter.

Made for Nokia XpressMusic

This product has been designed for use with Nokia XpressMusic phones. Extensive testing has been carried out with these phones to make sure you will get the best out of your phone in combination with this Philips product.



Issue date 2009-01-11

Version: 3.0.5

12 NC: 8670 000 35614
EAN: 87 12581 38369 5

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com