

Philips
Classic micro music system

• DAB

MCB395

Obsessed with sound

Relax with great music

Enjoy superb clarity with built-in DAB tuner with the Philips classic micro music system. It will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

Enjoy your music from multiple sources

- DAB for a clear and crackle-free radio experience
- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- FM digital tuning with presets

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2×50 W RMS and 2×100 W music power

Refined in sound and look

- Easy-to-use remote control included
- Elegant wood-finished speakers



Highlights

DAB

DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music

will be played directly from the device. Now you can share your favourite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

















Specifications

Sound

- Output power: 2 x 50 W RMS / 2 x 100 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 4" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/programme
- Others: ID3-tag support
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo, DAB (Band III)
- RDS: station name, radio text, RDS clock set
- Station presets: 40
- · Antenna: FM antenna
- DAB: info display, menu, smart scan
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- · Clock: on main display, sleep timer
- · Loader type: tray
- Display type: LCD display

Accessories

- · Remote control: 40-key with lithium battery
- Others: FM/MW antenna, Quick start guide
- User Manual

Dimensions

- Gross weight: 9.1 kg
- Main speaker dimensions (W x D): 152 x 257 mm
- Main speaker height: 228 mm
- Main unit depth: 285 mm
- Packaging width: 494 mm
- Main unit height: 228 mm
- Packaging height: 371 mm
- Main unit width: 152 mm
- Packaging depth: 275 mm

Power

- Power supply: 50 Hz
- Power supply: 220 240 V

Green

• Eco Power standby: 1 W



Issue date 2013-05-10

Version: 1.0.10

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 38712

EAN: 87 12581 41025 4 www.philips.com