



Philips  
Universal remote control

4in1 TV/DVD/SAT/AMP

SRU7040



# Home entertainment control

Operates more than 1200 brands

If you own a Flat TV and matching home entertainment center, this stylish ultra flat remote is the finishing touch! The slim remote provides all main functions of your home entertainment equipment in one fun small package.

## Single control solution for most devices & brands

- 4-in-1 remote for your TV, STB, DVD and Receiver
- Convenient IR learning from another remote
- Ready for use with Philips equipment

## Great convenience

- Ultraflat design matching flat home entertainment devices
- Dedicated keys for moving around menus
- A light indicates current active device mode
- Battery low indication shows when to refresh batteries

## Quick and easy set-up

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

**PHILIPS**

# Specifications

## Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P
- Number of keys: 38
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof

## Power

- Battery lifetime: 12 Months
- Number of batteries: 2

## Infrared Capabilities

- Operating distance: 7 m
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 300
- Carrier frequency range: 28 - 70kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 30 kHz - 60 kHz

## Accessories

- Battery: Yes, CR2032 Coin cell Battery 3V Lithium

## Outer Carton

- Length: 306 mm
- Width: 70 mm
- Height: 160 mm
- EAN/UPC/GTIN: 87 10895 93579 1
- Quantity: 3

## Packaging Data

- 12NC: 908210006464
- EAN/UPC/GTIN: 87 10895 93578 4
- Height: 26 mm
- Length: 302 mm
- Width: 155 mm

# Highlights

## 4in1 home entertainment remote

Replace a table full of remote controls with one unit that'll operate your TV, satellite receiver (or cable STB set-top box) DVD player/recorder and receiver (AMP), regardless of the brand or model.

## Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

## Ultra flat

A remote with ultraflat design is slimmer than a standard remote. This is made possible by replacing the standard batteries by coin cell batteries (the size of a coin) that take less space.

## Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

## Device mode indicator

Small lights keep you informed about which device mode is currently active.

## Battery-low indication

To know in time when the batteries need to be recharged or replaced.

## Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2017-04-04

Version: 2.0.8

12 NC: 9082 100 06464  
EAN: 87 10895 93578 4

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)