

Philips
SoundBar DVD home
theater

HTS6100



5.1 home theater from one bar

with Ambisound

Enjoy 5.1 surround sound in any sort of room, in any sitting position. Featuring Ambisound, this one-piece integrated system fits underneath any flat TV and provides a thrilling listening experience with excellent sound and picture quality.

Hear and see

- Ambisound for 5.1 surround sound from fewer speakers
- Excellent sound quality with soft dome tweeters & DoubleBASS
- HDMI 1080p upscales to high definition for sharper pictures

Live

- SoundBar with integrated speakers, amplifiers and DVD player
- Matches any flat TV with optimal fit for 37" TV or larger

Connect

- Dock your iPod for audio playback
- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- MP3 Link plays music from portable media players

Use

- EasyLink controls all EasyLink products with a single remote




asimpleswitch.com

PHILIPS
sense and simplicity

Highlights

Ambisound




Ambisound technology produces truly embracing multi-channel surround sound from fewer speakers. It delivers an immersive 5.1 sound experience without the constraints of sitting position, room shape or size, and without the clutter of multiple speakers and cables. Through the combined effect of psychoacoustic phenomena, array processing and precisely angled driver positioning, Ambisound delivers more sound from fewer speakers.

SoundBar



The SoundBar is a complete all-in-one home theater solution that delivers superb 5.1 surround sound for an immersive movie experience. Integrating speakers, amplifiers and DVD player, the SoundBar is all you need below your television. It lets you keep your living room the way you want it, yet delivers an amazing multichannel sound experience - for movie moments shared with friends and family.

Dock your iPod



The docking station, included with your home theater system, lets you play music from your iPod. What's more, you can control the iPod with the home theater system's remote. The docking station brings portable entertainment into your living room - with absolute convenience.


HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect

picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link



The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

EasyLink



EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.



Specifications

Picture/Display

- Picture enhancement: High Def (720p, 1080i, 1080p), Video upscaling

Sound

- Sound System: Ambisound, Dolby Digital, Dolby Prologic II, DTS, Stereo
- Sound Enhancement: Treble and Bass Control, Smart Surround, DoubleBass, ClearVoice, FullSound
- Equalizer settings: Action, Rock, Concert, Classic, Drama, Jazz, Gaming, Party, News, Sports

Loudspeakers

- Loudspeaker types: Integrated with main unit
- Speaker Drivers: 2 x 1" Soft Dome tweeters, 6 x 2.5" Full Range woofers
- Speaker Impedance: 6 ohm
- Subwoofer type: Active
- Subwoofer driver: 1 x 6.5" Long Throw woofer
- Subwoofer impedance: 4 ohm
- Subwoofer freq range: 35-200 Hz

Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: PAL, NTSC

Audio Playback

- Compression format: MP3, WMA
- Playback Media: Audio CD, CD-R/RW, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture compression format: JPEG
- Playback Media: CD-R/RW, DVD+R/+RW, USB

flash drive

- Picture enhancement: Slideshow with music playback, Rotate, Zoom

Tuner/Reception/Transmission

- Tuner Bands: FM, AM

Connectivity

- Front / Side connections: Dock connector, USB, MP3 Line-in
- Rear Connections: HDMI output, Component Video output, Composite video (CVBS) output, TV in (audio, cinch), Easy-Fit speaker connectors, Interconnect (to Power Box)
- Subwoofer (Power Box): FM Antenna, AM/MW Antenna, Coaxial Digital input, AUX In (cinch, 2 pairs), Interconnect (to Main Unit)

Dimensions

- Set dimensions (W x H x D): 958 x 163 x 141 mm
- Set weight: 7 kg
- Subwoofer dimensions (W x H x D): 295 x 440 x 295 mm
- Subwoofer Weight: 10 kg
- Packaging dimensions (W x H x D): 1025 x 354 x 550 mm
- Weight incl. Packaging: 30.4 kg

Accessories

- Included Accessories: Quick start guide, User Manual, Dock for iPod, Remote Control, Batteries for remote control, HDMI cable, CVBS video cable, FM antenna, AM antenna, Interconnect cable, Power cord, Wall mounting bracket, World Wide Warranty leaflet

Power

- Power supply: 100-240VAC, 50/60Hz
- Standby power consumption: <0.3 W



Issue date 2009-06-12

Version: 1.0.6

12 NC: 8670 000 40085
EAN: 87 12581 42662 0

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com