



Philips
DVD Micro Theatre

HDMI 1080p



MCD388

Bring cinema experience to life

with Dolby Virtual Speaker

Experience audio and video like never before with the wall-mountable Philips Micro Theatre MCD388. Playback from multiple sources. Full High-Definition Multimedia Interface (HDMI) produces sharper images.

Enrich your sound experience

- Digital wireless active subwoofer for powerful bass
- USB Direct and SDHC card slots for music and video playback
- MP3 Link for portable music playback
- Digital Sound Control for optimised music style settings
- Loudness for bass and treble enhancement
- Dynamic Bass Boost for deep and dramatic sound
- Total 100 W RMS

Enrich your movie experience

- Dolby Virtual Speaker for theatre audio experience
- HDMI 1080p upscales to high definition for sharper pictures
- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD

Design that blends into your interior

- Stylish slim design with table-stand and wall-mount options

PHILIPS

Highlights

Digital wireless subwoofer

The digital wireless subwoofer is optimised to reproduce bass frequencies. The result is a powerful reproduction of deep bass with the minimum of distortion.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. With the Loudness feature activated, the bass and treble will be amplified so you can savour a more balanced sound perception overall.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Dolby Virtual Speaker

Dolby Virtual Speaker is a sophisticated audio virtualisation technology that produces rich and immersive surround sound from a two-speaker system. Highly advanced spatial algorithms faithfully replicate the sonic characteristics that occur in an ideal 5.1-channel environment. DVD playback is enhanced by expanding the 2-channel environment. When combined with Dolby Pro Logic II processing, any high-quality stereo source is transformed into true-to-life, multi-channel surround sound. No need to purchase extra speakers, wires or speaker stands to appreciate room-filling sound.

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition

resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multi-channel audio, without conversions to analogue - delivering perfect picture and sound quality, completely free from noise.

USB Direct and SDHC card slots

Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more music, videos and photos via the built-in USB Direct and SDHC card slots.

MP3 Link for portable music

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.



Specifications

Sound

- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness, Class "D" Digital Amplifier
- Sound System: Dolby Digital, Dolby Virtual speaker
- Output Power: Total 100 W RMS
- Output power (RMS): 2 x 20 W RMS + 60 W

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 3" woofer
- Subwoofer type: Active
- Loudspeaker types: Non-detachable

Video Playback

- Playback Media: DivX, DVD-Video, Video CD/ SVCD, Picture CD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Zoom, Parental control, Disc Menu, Fast Reverse, Fast Forward, OSD, Slow Motion, Resume Playback from Stop
- Loader Type: Slot
- DVD Region.: 2

Picture/Display

- Picture enhancement: High Def (720p, 1080i, 1080p), Video upsampling, Video upscaling

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: Picture CD, CD-R/RW, DVD+R/+RW

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, SD/MMC card, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- ID3-tag support
- Loader Type: Slot, Motorised
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning

- RDS: Station Name, RDS Clock Set, Programme Type
- Tuner Enhancements: Auto Store
- Station presets: 20

Connectivity

- Headphones: 3.5 mm
- Other connections: FM Antenna, Digital audio coaxial out, HDMI out
- Video Output - Analogue: S-Video (on Hosiden), Component Y Pb Pr (cinch), Composite CVBS (yellow cinch)
- USB: USB host
- Audio Connections: Analogue Audio In (L/R)
- 3.5 mm stereo line in: MP3 Link

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- OSD Languages: English, Portuguese, Spanish, Dutch, French, German, Italian, Swedish, Turkish
- Indications: DIM mode
- Eco Power Standby: 1 watt
- Wall mountable/Ceiling Throw: Wall Mountable

Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet, AC Power Cord, Composite video cable (Y), Scart adapter
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- Remote control: 40-key remote with lithium battery
- User Manual: 16 languages
- Cables: MP3 line-in cable

Dimensions

- Packaging dimensions (W x H x D): 565 x 350 x 250 mm
- Set dimensions (W x H x D): 525 x 235 x 120 mm
- Subwoofer dimensions (W x H x D): 170 x 195 x 300 mm
- Weight incl. Packaging: 8 kg

Power

- Power supply: 110-240V, 50/60 Hz



Issue date 2016-12-14

Version: 1.0.12

12 NC: 8670 000 42788
EAN: 87 12581 44685 7

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com