



#### Wireless Headphone

- Active Noise Canceling
- Slim and lightweight
- Multipoint pairing

TAH6506BK/00

## Every moment. Every day.

These strikingly slender wireless headphones are all about focus. Wherever you listen, Active Noise Canceling lets you sink into the music you love. Multitasking is easy too-you can pair simultaneously with two devices.

### Benefits

#### Sleek design. Seamless control.

- Focused on your music. Active Noise Canceling
- Slim over-ear design. Distinctive looks
- Bluetooth multipoint connectivity. Work better
- 30 hours play time. 25 with Active Noise Canceling

#### Lightweight comfort for music and calls

- Integrated controls. Clear calls
- Powerful 32 mm neodymium drivers

- Easily wake your phone's voice assistant

#### From home office to commute

- Easy storage. Flat-folding and compact-folding design
- Included soft pouch
- Charge for 15 minutes, get 2 hours extra play time
- Compatible with an audio cable (3.5 mm jack)

# PHILIPS

Features

Active noise canceling



Want to reduce noise when you're on the go? Internal mics in the ear cups of these wireless over-ear headphones filter out the engine noise you don't want to hear, so you're free to be with the tunes you love.

Bluetooth multipoint



Streamline your working day. These wireless headphones can connect to two Bluetooth devices at the same time-and switch between them as you need. So you can listen to music from your laptop and take calls from your phone.

Specifications

[field not found 'disclaimer\_text']

Sound

Impedance	32 Ohm
Speaker diameter	32 mm
Sensitivity	112 dB (1K Hz)
Frequency range	20 - 20,000 Hz
Maximum power input	20 mW
Driver type	Dynamic

ANC features

ANC (Active Noise Canceling)	Yes
ANC technology	FB
Adaptive ANC	Yes
Microphone for ANC	2 mic

Telecommunication

Microphone for call	1 mic
---------------------	-------

Connectivity

Bluetooth version	5.0
Supported codec	SBC
Maximum range	Up to 10 m
Bluetooth profiles	A2DP AVRCP HFP
Detachable cable	Yes
Multipoint connection	Yes
Type of wireless transmission	Bluetooth
Wireless	Yes
Headphone socket	3.5 mm

Convenience

Type of controls	Button
Automatic power off	Yes

30 hours play time

With 30 hours play time from a single charge-or 25 hours with Active Noise Canceling activated-these wireless on-ear headphones are with you all day long. A full charge takes 2 hours. Need an extra boost? 15 minutes charging gives you 2 hours more play time.

Easy control and pairing

Buttons and a dial on the ear cups let you pause your playlist, take calls, control volume, and wake your phone's voice assistant. Calls are nice and clear, and you can pair your headphones with two devices simultaneously.

Easy storage

The ear cups swivel to allow the headphones to fold flat-perfect for storing in your office drawer. Or you can fold them flat and inwards, creating a compact bundle that easily fits into the included soft pouch.

Design

Color	Black
Foldable design	Flat / In-ward
Wearing style	Headband
Ear fitting	Over-ear
Earcup type	Closed-back
Ear coupling material	Synthetic leather

Power

Music play time (ANC off)	30 hr
Music play time (ANC on)	25 hr
Talk time	30 hr
Battery type(Head-phones)	Lithium Polymer (built-in)
Battery capacity(Head-phones)	300 mAh
Charging time	2 hr
Fast charging time	15 mins for 2 hrs
Number of batteries	1 pcs
Battery weight (Total)	7.08 g
Rechargeable	Yes

Voice assistant

Voice assistant support	Yes
Voice assistant activation	Manual
Voice assistant compatible	Apple Siri Google Assistant

Accessories

Audio cable	3.5mm stereo cable, L=1.2m
Carrying case	1 pcs Soft case
Charging cable	USB-C cable, 500 mm
Quick Start Guide	Yes

#### Outer Carton

Number of consumer packagings	3
Length	20.5 cm
Width	15.5 cm
Height	24 cm
Gross weight	1.086 kg
Nett weight	0.435 kg
Tare weight	0.651 kg
GTIN	1 48 95229 11759 1

#### Packaging dimensions

Packaging type	Box
Number of products included	1
Type of shelf placement	Hanging
Height	22.5 cm
Width	18.5 cm
Depth	4.5 cm
Gross weight	0.293 kg

Nett weight	0.145 kg
Tare weight	0.148 kg
EAN	48 95229 11759 4

#### Product dimensions

Height	19 cm
Width	16.5 cm
Depth	3.8 cm
Weight	0.145 kg

#### UPC

UPC	8 40063 20195 8
-----	-----------------



\* Battery life of playtime is approximate and may vary depending on application condition.



data subject to change  
2023, June 18

Version: 7.1.3  
EAN: 4895229117594

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)