



Philips
docking entertainment
system with Dynamic Bass
Boost

- USB Direct
- FM digital tuner
- MP3 Link



DC185

Enjoy iPod & MP3 music out loud anywhere you go

Free your iPod music and enjoy it out loud on the Philips DC185 with powerful 2x2W sound. Share all your tunes and liven up any party, or just plug in your USB device to enjoy your favorite music on the go.

Enrich your sound experience

- Play and charge your iPod simultaneously
- USB Direct for MP3/WMA music playback

Superb performance in a compact design

- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

Easy to use

- FM digital tuning with presets
- Aux-in connection for your portable MP3 music player

PHILIPS

Specifications

iPod compatibility

- Compatible with: iPod touch, iPod classic, iPod nano 3rd Generation, iPod 5th Generation, iPod with color display, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

Connectivity

- USB: USB host
- Aux in
- Headphone: 3.5 mm

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and backward
- Playback Media: USB flash drive
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

Sound

- Output power (RMS): 2x2W
- Sound System: Stereo

- Sound Enhancement: Dynamic Bass Boost
- Volume Control: Volume Control up/down
- Speaker diameter: 3"

Loudspeakers

- Built-in speakers: 2

Convenience

- Display Type: LCD
- User convenience: Sleep Timer

Power

- Mains power
- Battery type: C / LR14 Alkaline
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

- Included accessories: AC Power Cord, 3.5mm stereo line in cable, User Manual, Warranty certificate

Dimensions

- Product dimensions (W x H x D):
348 x 127 x 238 mm
- Packaging dimensions (W x H x D):
373 x 157 x 262 mm

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 41385
EAN: 87 12581 43527 1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com