

Philips
Classic DVD micro system

100W

MCD395



Obsessed with sound

Relax with great music and movies

You are in touch with the latest and the coolest - now get a load of the hot 2-in-1 Philips classic DVD micro system with DVD, WMA-CD and MP3-CD playback. Relax to your favorite music and movies. Home entertainment will never be the same again.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- USB Direct for music and photo playback
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x50W RMS and 2x100W music power

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

PHILIPS

Highlights

Play DVD, DivX & MP3/WMA-CD

The Philips player is compatible with most DVD and CD discs available in the market. DVD, DivX®, (S)VCD, MP3/WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.

USB Direct

Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.



Specifications

Sound

- Output power: 2 x 50 W RMS / 100 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost, loudness, Dolby Digital

Loudspeakers

- Speaker drivers: 4" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Video Playback

- DVD region code: 2
- Playback media: DivX, DVD-Video, picture CD, video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc playback modes: A-B Repeat, angle, Zoom, slow motion, parental control, PBC, disc menu, fast backward, fast forward, OSD, resume playback from stop

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 40
- Antenna: FM antenna
- RDS: RDS clock set, station name, radio text
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: 2xRCA (Audio), composite video (CVBS) out, digital audio coaxial out, Headphone (3.5mm), subwoofer out, S-Video out

- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: motorised, tray
- On-Screen display languages: Dutch, English, French, German, Italian, Portuguese, Spanish, Swedish, Turkish
- Display type: LCD display

Accessories

- Cables/Connection: composite video cable (Y)
- Remote control: 40-key with lithium battery
- Others: FM antenna, Quick start guide
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 9.9 kg
- Main speaker dimensions (W x D): 152 x 257 mm
- Main speaker height: 228 mm
- Main unit depth: 285 mm
- Packaging width: 494 mm
- Main unit height: 228 mm
- Packaging height: 371 mm
- Main unit width: 152 mm
- Packaging depth: 275 mm

Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

Green

- Eco Power standby: 1 W

Digital photo playback

- Playback media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, picture CD
- Picture Compression Format: JPEG



Issue date 2014-02-05

Version: 1.0.5

12 NC: 8670 000 37569
EAN: 87 12581 39989 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com