

## all-in-one, impressive MP3 music

Compact and stylish, this all-in-one CD player plays all CDs, including MP3-CD. Sit back and enjoy music convenience with its programmable 20 track replay.



### Feature-packed CD player

- MP3-CD, CD-R/RW compatible
- CD shuffle/program/repeat

### Impressive sound

- Dynamic Bass Boost delivers deeper, more dramatic bass
- Bass Reflex speakers deliver a powerful, deeper bass

### Easy to use and precise control

- Digital tuning with presets
- Autostore Programming for one-touch radio tuning
- Remote control



## Technical specifications

### Sound

- **Output power (RMS):** 2X1.2W
- **Sound System:** Stereo
- **Volume Control:** Volume Control up/down
- **Speaker diameter:** 4"
- **Loudspeaker types:** Bass Reflex Speaker System
- **Sound Enhancement:** Dynamic Bass Boost

### Audio Playback

- **Loader Type:** Top
- **Disc Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- **Programmable Tracks:** 20
- **Number of decks:** 1
- **Cassette Deck Technology:** Mechanical
- **Cassette Playback Modes:** Fast Wind/Rewind, Full Auto Stop, Pause key

### Tuner/Reception/Transmission

- **Auto digital tuning**
- **Station presets:** 20
- **Antenna:** AM Antenna, FM Antenna
- **Tuner Bands:** FM, AM

### Connectivity

- **Headphone:** 3.5 mm

### Convenience

- **Display Type:** LCD
- **Remote control:** 14 keys

### Accessories

- **Included Accessories:** AC Power Cord, User Manual, Warranty certificate

### Power

- **Mains power**
- **Battery Type:** LR14
- **Battery Voltage:** 1.5 V
- **Number of batteries:** 6

### Dimensions

- **Packaging dimensions (W x H x D):** 470 x 275 x 210 mm
- **Product dimensions (W x H x D):** 400 x 243 x 169 mm
- **Weight:** 2.9 kg
- **Weight incl. Packaging:** 3.7 kg

## Product highlights

### MP3-CD, CD-R/RW compatible

### Digital tuning with presets

### Dynamic Bass Boost

*Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.*

### Bass Reflex Speaker System

*Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.*

### CD shuffle/program/repeat

### Autostore programming

*Autostore Programming is a convenient feature that allows you to tune in to your favorite stations and set station presets by simply pressing a button. Autostore Programming does away with the hassle of manual radio station tuning and setting of presets. A built-in electrical circuit automatically scans local radio station frequencies, locks on to the strongest radio station signals, and assigns them to specific presets.*

### Remote control



Date of issue 2005-04-04

12 NC: 9073 101 01994

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.  
© 2005 Koninklijke Philips Electronics N.V.  
All Rights reserved.  
[www.philips.com](http://www.philips.com)