

Philips CD Soundmachine

AZ1123

Music on the move

Compact and stylish, this all-in-one player plays all CDs including CD-R and CD-RW. Sit back and enjoy music convenience with its programmable 20 track replay.

Enjoy your music from different sources

- CD player
- Compatible with CD-Recordable and CD-ReWritable
- FM/MW stereo tuner

Easy to use

- CD shuffle/program/repeat
- Multi-functional LCD display
- Stereo headphone socket



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle
- Loader Type: Top
- Programmable Tracks: 20

Tuner/Reception/Transmission

- · Antenna: FM Antenna
- Tuner Bands: FM, AM

Sound

- Output power (RMS): 2x1W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Convenience

- Display Type: LCD
- Display Digits: 2



Connectivity

· Headphone: 3.5 mm

Power

- Battery type: LR14Battery voltage: 1.5 V
- · Mains power
- Number of batteries: 6

Accessories

• Included Accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 397 x 169 x 246 mm
- Product dimensions (W x H x D): 350 x 127 x 217 mm
- Weight: 1.9 kg
- Weight incl. Packaging: 2.55 kg

Highlights

CD player

CD player

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW stereo tuner

FM/MW stereo tuner

CD shuffle/program/repeat CD shuffle/program/repeat

Multi-functional LCD display Multi-functional LCD display

Stereo headphone socket

Stereo headphone socket



Issue date 2015-01-22

Version: 1.0.7

© 2015 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 101 02729 UPC: 6 09585 11434 0

www.philips.com