

Philips  
Classic micro sound  
system

DAB

MCB395



## Obsessed with sound

Relax with great music

Enjoy superb clarity with built-in DAB tuner with the Philips classic micro music system. It will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

### Enjoy your music from multiple sources

- DAB for clear and crackle-free radio experience
- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- FM digital tuning with presets

### Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x50W RMS and 2x100W music power

### Refined in sound and look

- Easy-to-use remote control included
- Elegant wood-finished speakers

# PHILIPS

# Highlights

## DAB

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music

will be played directly from the device. Now you can share your favorite moments with family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output power: 2 x 50 W RMS / 2 x 100 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Speaker drivers: 4" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

## Tuner/Reception/Transmission

- Tuner bands: FM stereo, DAB (Band III)
- RDS: station name, radio text, RDS clock set
- Station presets: 40
- Antenna: FM antenna
- DAB: info display, menu, smart scan
- Tuner enhancement: auto digital tuning, auto scan

## Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

## Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: tray
- Display type: LCD display

## Accessories

- Remote control: 40-key with lithium battery
- Others: FM/MW antenna, Quick start guide
- User Manual

## Dimensions

- Gross weight: 9.1 kg
- Main speaker dimensions (W x D): 152 x 257 mm
- Main speaker height: 228 mm
- Main unit depth: 285 mm
- Packaging width: 494 mm
- Main unit height: 228 mm
- Packaging height: 371 mm
- Main unit width: 152 mm
- Packaging depth: 275 mm

## Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

## Green

- Eco Power standby: 1 W



Issue date 2014-02-07

Version: 1.0.10

12 NC: 8670 000 38712  
EAN: 87 12581 41025 4

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)