

Philips
Car entertainment system



CSP6920

Your mobile music theater

with 5-way stereo for powerful sound

Feel your music with the Philips Car stereo speakers CSP6920. These 16x24cm 5-way speakers have peak power at 480W, and feature an oval fiber composite cone with a soft PEI dome tweeter so you can enjoy vivid music details and deep bass.

Powerful music on the road

- 80W RMS power handling
- Fiber-composite cone delivers sound with lowest distortion
- Soft PEI dome tweeter for warm and textured tones
- Butyl rubber surround for maximum smooth response
- Strong ferrite magnet for high power performance

High durability, sustainable performance

- Sturdy polypropylene cone for all-weather performance
- Stylish speaker grille protects against damages
- Endurance and performance stability in extreme conditions

Easy to use and install

- Fits perfectly in all 16x24cm speaker openings
- Simple wires plug-in for designated speaker terminals

PHILIPS
sense and simplicity

Specifications

Loudspeakers

- Speaker type: Coaxial speaker
- Number of ways: 5-way
- Speaker size: 16x24cm (6x9")
- Number of Loudspeakers: 2

Sound

- Output power (RMS): 80W
- Peak Music Power: 480W
- Sensitivity: 91dB
- Frequency response: 27-33k Hz
- Impedance: 4 Ohms

Woofers

- Diaphragm: Cone
- Diaphragm material: Fiber-composite
- Surround: Rubber
- Voice coil: Single
- Voice coil material: Copper
- Magnet: Ferrite
- Magnet mass: 22 Oz
- Damper: Conex

Mid-range

- Size: 55 mm (2-1/6")
- Diaphragm: Cone

- Diaphragm material: Paper
- Magnet: Neodymium

Tweeter

- Size: 25mm (1")
- Diaphragm: Dome
- Diaphragm material: PEI
- Magnet: Neodymium

Supertweeter

- Diaphragm: Dome
- Diaphragm material: PEI
- Size: 15mm (3/5")

Accessories

- Speaker grille: With metal net
- Quick start guide: English, Spanish, Portuguese, Russian
- Cables: Speaker wires

Dimensions

- Product dimensions (W x H x D):
263 x 104 x 192 mm
- Mounting depth: 88 mm
- Tweeter protrusion: 15 mm



Issue date 2011-10-18

Version: 1.0.3

12 NC: 8670 000 56267
EAN: 87 12581 50456 4

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com