



Philips
Surge protector

Home theater
4 outlets

SPN5044A



Eliminate Cable Clutter

Designed to perform and protect, this surge protector features advanced technologies to keep equipment safe from electrical surges. Power Blocker® circuitry automatically shuts down power to your system to protect against subsequent surges.

Pure Protection

- 1800 Joules
- Protected coax connections
- €150.000 equipment warranty
- Power Blocker

Built-in convenience

- 4 outlets with protection
- 2 m power cord
- Built in cord management

Simplicity

- Integrated automatic child safety outlets
- Worry free protection indicators

PHILIPS

Surge protector
Home theater 4 outlets

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D):
14 x 38 x 5.5 cm
- Nett weight: 0.579 kg
- Gross weight: 0.675 kg
- Tare weight: 0.096 kg
- EAN: 87 12581 51876 9
- Number of products included: 1
- Packaging type: Box

Outer Carton

- Outer carton (L x W x H): 38 x 18.5 x 16 cm
- Nett weight: 1.737 kg
- Gross weight: 2.305 kg
- Tare weight: 0.568 kg
- EAN: 87 12581 54572 7
- Number of consumer packagings: 3

SPN5044A/19

Highlights

1800 Joules

Prevent thousands of dollars of damage to your electronic devices.

Protected coax connections

Connectors route the coaxial signal through the surge protector to protect against surges and spikes.

Power Blocker

Automatically shuts down power to the connected devices.

€150.000 equipment warranty

Protects your connected equipment for the life of the product.

4 outlets with protection

Protects against surges/spikes through the AC lines by suppressing surge energy. The excess energy is clamped by the MOV when the unit is subjected to a surge event.

2 m power cord

Provides power to the unit which can be 2 m from the AC outlet.

Cord Management

A cord management device that allows the cable/cords to be routed in the same direction for a more organized appearance

automatic child safety outlets

Helps keep children safe from accidental shock.

Protection indicators

LED lights let you know if your surge protector is functioning properly.



Issue date 2014-02-12

Version: 1.3.5

12 NC: 8670 000 58702
EAN: 87 12581 51876 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com