

Philips Streamium
Wireless Music Adapter

Streamium

SL501



Music here, PC there without wires

PC and Internet Music wirelessly on your stereo

Enjoy music wirelessly from your PC

- Stream high-quality music from your PC to the audio system
- Enjoy music files from your PC wirelessly on your stereo

Wireless access to Internet Music

- Choose your favourite Internet music to fit your mood
- Internet upgradeable to keep your product up to date
- Access to Internet Music Entertainment

Ease of Use

- Local LCD display for easy navigation
- Control all the functions you need with fingertip ease
- Gain easy access to your list of favourite content

Based on open standards

- Wireless RF communication based on open IEEE802.11 standard
- UPnP enables various devices to communicate with each other

PHILIPS

Technical specifications

Audio Playback

- **Compression format:** MP3, MP3PRO
- ID3 tag support

Connectivity

- **Audio output - analogue:** Stereo (Red / white cinch)
- **Encryption / security:** WEP 128bit, WEP 64bit
- **Wireless connections:** Wireless LAN(802.11b/g)

Accessories

- **CD-ROM:** Philips Media Manager & manual
- **Included accessories:** AC power cord, Audio cable, Batteries for remote control, Mains Adaptor, Remote control, User manual
- Remote control
- User manual

Software

- **Philips Media Manager:** UPnP multimedia content server

System Requirements

- CD-ROM drive
- **Hard disc space:** 100 MB
- **PC OS:** Windows® 98 SE, 2000, ME, XP
- **Processor:** Pentium II or better
- **RAM memory:** 64 MB
- **PC network required:** Wireless Network
- **Internet connection:** Broadband Internet (>256 kbps)
- **My.philips.com:** Internet access and email

Power

- **Mains power:** AC 100-240V 50-60Hz
- On/Off switch
- **Power LED indicator:** Operation - Blue, Red

Internet services

- **Audio services:** Live 365.com, Andante, Musichmatch Jukebox, Radio Free Virgin, Playhouse radio, ...and more
- **My streams:** Add your own Internet streams

Product highlights

Wireless PC Music Link

Stream music from your PC to your audio system in high quality. Listen on your audio system to music files stored on the PC. Select songs from your music collection according to artist, album or genre.

Wireless PC music

Bring music stored on your PC to your stereo via a wireless connection and enjoy it anywhere in your home.

Internet Music Entertainment

A broadband Internet connection gives you access to a huge collection of music content that is live streamed from the Internet to your Wireless Music Link. Today's selection of Internet Entertainment consists of: - 1,000s of Internet Radio stations - Access to almost any music genre - Personalised Internet Audio - create your own station - Free and subscription based services - My Streams gives access to any MP3 format radio station on the web

Internet upgradeable

New features, functions and media formats automatically downloaded over the Internet via a broadband connection straight into your device.

Customised Internet Music

Choose by genre from thousands of Internet music stations to fit your mood. Personalise Internet Radio to your music preferences.

WiFi 802.11

The WiFi standard means that no wires need to be installed between PC devices, PC peripherals and audio / video equipment located in different rooms.

UPnP

UPnP (Universal Plug and Play) refers to a networking protocol that allows various devices to communicate with each other. Devices that can play certain content (pictures, audio or video files) can make themselves know on the network and can link into datastores that hold these files. A file can then be exchanged to enjoy a seamless entertainment experience.

LCD navigation display

Local LCD display facilitates easy navigation through your music collection.

Favourites

You can create a list in which you mark or unmark your favourite content using the remote control. Then simply use the list to quickly playback this content.

Infra-red remote control

Infra-red remote control provides the most convenient way to control the device without leaving your chair.



Date of issue 2006-07-07

Version: 2.0

12 NC: 9082 100 03004
EAN: 87 10895 82089 9

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com