



Philips
CD Soundmachine

DAB
CD

AZB200

Enjoy music wherever you go

Bring big sound out with you for music on the go with this portable stereo system equipped with DAB, FM radio and multi-type CD playback

Enjoy your music from multiple sources

- DAB+, DAB and FM for full radio experience
- Play CD, CD-R and CD-RW
- Audio-in for easy portable music playback

Easy to use

- 20-track CD programmable
- CD Shuffle/Repeat for personalised music enjoyment

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme

Convenience

- Loader type: top
- Display type: LCD display

Tuner/Reception/Transmission

- Tuner bands: FM
- Antenna type: Telescopic
- DAB/DAB+: Info display, Menu
- Tuner enhancement: auto digital tuning

Sound

- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS
- Sound system: stereo

Loudspeakers

- No. of built-in speakers: 2

Connectivity

- Audio in (3.5 mm)

Accessories

- Cables/Connection: AC-DC adapter
- User Manual
- Warranty: Warranty leaflet

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: 100-240 V

Dimensions

- Packaging depth: 159 mm
- Packaging height: 244 mm
- Packaging width: 262 mm
- Main unit depth: 212 mm
- Main unit height: 131 mm
- Main unit width: 240 mm
- Weight incl. Packaging: 1.9 kg
- Product weight: 1.4 kg



Highlights

DAB+, DAB and FM

DAB+/DAB (Digital Audio Broadcasting) digital radio is, on top of FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB+ or DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

Play CD, CD-R and CD-RW



Philips is known for making products that are compatible with many discs available on the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favourite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

20-track CD programmable

The CD programmable playback feature allows you to enjoy your favourite tracks in the order you want.



Issue date 2023-05-06

Version: 2.0.4

12 NC: 8670 001 48442
EAN: 69 51613 99083 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com