



Philips
Digital PhotoFrame

17.8cm (7")



SPF1307

"...couldn't stop laughing that day!"

Keep your most memorable moments alive year round with Philips PhotoFrame. This compact frame is easy to use, has lots of storage memory and looks good in any home environment.

Top quality display for amazing viewing experience

- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Auto photo orientation to fit portrait or landscape modes
- Have fun with collages: display mutiple photos in one view



asimpleswitch.com



asimpleswitch.com

PHILIPS

sense and simplicity

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 16:10
- Panel resolution: 480 x 234
- Effective viewing area: 432x234 (13.9x8.7cm)
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Storage Media

- Built-in memory capacity: 128MB (for 100 HD photos)
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adaptor), MS Pro Duo (via adaptor)

Convenience

- Card Reader: Built-in (1x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter, Power button
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Slideshow, Clock display enable/disable
- Regulatory approvals: CE, GOST, Switzerland
- Other convenience: Kensington lock compatible

Accessories

- Included accessories: AC-DC Adapter, Quick start

guide, User manual on CD-ROM

- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Korean, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power supply: 100-240VAC, 50/60Hz
- DC output Volt: 9 V
- Power mode supported: AC powered
- DC output Ampère: 1 A
- Power consumption: (System on) 5.6 W

Packaging dimensions

- Packaging dimensions (W x H x D): 26.1 x 22.2 x 7.8 cm
- Nett weight: 0.6 kg
- Gross weight: 0.799 kg
- Tare weight: 0.199 kg
- EAN: 87 12581 54726 4
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 28.3 x 24.3 x 18.8 cm
- Nett weight: 1.2 kg
- Gross weight: 2.1 kg
- Tare weight: 0.9 kg
- GTIN: 1 87 12581 54726 1
- Number of consumer packagings: 2

Highlights

imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those moments you don't want to spend time copying photos to your PhotoFrame.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.



Issue date 2013-02-09

Version: 5.0.3

12 NC: 8670 000 63688
EAN: 87 12581 54726 4

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com