

Philips
Universal remote control

SRU4002X



EasyZapper

Operates more than 800 brands

A simple and smart universal remote control for easy channel hopping on your TV and satellite receiver, cable or DVB-T set-top box regardless of brand.

Single control solution for most devices and brands

- You can control: TV and Set-Top Box

Ideal replacement for your old remote

- Ideal replacement for broken Philips TV remote controls

Great convenience

- Direct access to your favourite channels (4 out of 150)
- Ergonomic shape enables comfortable control
- Learning capability copies functions from original remotes

Quick and easy setup

- Ready for use with Philips equipment
- Automatically searches for your equipment brand
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS
sense and simplicity

Specifications

Convenience

- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P/CS/GR/RU/PL
- Number of keys: 19
- Pre-programmed for Philips
- Regulatory Approvals: CE Mark
- Simple system setup
- Splash-proof
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, AV selection, external, 16:9, Menu Control
- Universal IR database: TV, CABLE, DVB-T, SAT
- Languages in manual: GB/F/D/NL/DK/S/N/FIN/I/E/P/CS/GR/RU/PL
- SAT/CBL functions: Channel up/down, Favourites, Guide, info

Power

- Battery lifetime: 12 months
- Battery type: AAA
- Number of batteries: 2

Infrared Capabilities

- Operating distance: 33 ft (10 m)

- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 800
- Carrier frequency range: 24–55 kHz
- Transmission angle: 90 degree

Packaging dimensions

- Packaging dimensions (W x H x D): 15.7 x 24.2 x 4.6 cm
- Net weight: 0.0527 kg
- Gross weight: 0.22 kg
- Tare weight: 0.1673 kg
- EAN: 87 12581 44083 1
- Number of products included: 1
- Packaging type: Blister

Outer Box

- Outer carton (L x W x H): 33 x 26.5 x 19.5 cm
- Net weight: 0.3162 kg
- Gross weight: 1.94 kg
- Tare weight: 1.6238 kg
- EAN: 87 12581 44084 8
- Number of consumer packages: 6

Highlights

Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

Directly access your favourites

This remote has four favourite channels keys, which you can change to your favourite channel icon keys. Simply remove the ring around the favourite channel key, take off the transparent cover and replace the sticker with the channel icon of your favourite channel (out of the 150 stickers available). Now you can select your favourite channels directly.

Learning capability

To have all the functions of your original remote available you can copy the signal transmitted from the original remote. It is then stored in the memory of the Universal remote control.

Online URC service

Dedicated support service for your remote control whereby all codes for all brands are available via the Philips URC website.



Issue date 2010-08-20

Version: 1.0.18

12 NC: 8670 000 41964
EAN: 87 12581 44083 1

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com