

Philips Headphones with mic 14.8mm drivers/open-back Earbud



# SHE3015PH



# Extra bass

# Soft body for comfy fit

Philips SHE3015 headphones with soft body earbuds offer a comfortable fit. Available in eye-catching colors. The built-in mic and control make handsfree talking on mobile easy.

## Enjoy quality sound

- 14.8mm speaker drivers for high quality sound
- Neodymium magnets enhance bass performance and sensitivity

## Ultimate wearing comfort

- Soft body ensures a comfortable fit
- Rubberized front caps for wearing comfort

### **Design for convenience**

- Flexi-Grip design for durabilit
- Built-in microphone switches you from music to phone calls



# Specifications

# Design

#### · Color: Pink

#### Sound

- Acoustic system: open
- Magnet type: Neodymium
- Voice coil: copper
- · Diaphragm: PET
- Impedance: 16 ohm
- Maximum power input: 25 mW
- Sensitivity: 107 dB
- Speaker diameter: 14.8 mm
- Type: Dynamic
- Frequency response: 9 22 000 Hz

### Connectivity

- Cable Connection: two-parallel, symmetric
- Cable length: 1 m
- Connector: 3.5 mm
- · Finishing of connector: nickel plated
- Type of cable: copper

## **Packaging dimensions**

- EAN: 69 23410 73228 3
- Packaging dimensions (W x H x D): 5,2 x 17,5 x 2,8 cm
- Gross weight: 0,0339 kg

- Nett weight: 0,0134 kg
  - Number of products included: 1
  - Packaging type: Dummy
  - Tare weight: 0,0205 kg
  - Type of shelf placement: Dummy

#### Inner Carton

- Gross weight: 0,1287 kg
- GTIN: 2 69 23410 73228 7
- Inner carton (L x W x H):  $17,9 \times 8 \times 6$  cm
- Nett weight: 0,0402 kg
- Number of consumer packagings: 3
- Tare weight: 0,0885 kg

#### **Outer Carton**

- Gross weight: 1,2586 kg
- GTIN: 1 69 23410 73228 0
- Outer carton (L x W x H): 34,5 x 19,7 x 16,3 cm
- Nett weight: 0,3216 kg
- Number of consumer packagings: 24
- Tare weight: 0,9370 kg

#### **Product dimensions**

- Product dimensions (W x H x D):
- 1.6 x 2.1 x 1.25 cm
- Weight: 0,0134 kg

# SHE3015PH/00

# Highlights

#### 14.8mm speakers

Large 14.8mm speaker drivers squeezed into earbud headphones deliver high quality sound.

Flexi-grip A soft, flexible part protects the cable connection from damage that otherwise would occur due to repeated bending.

#### **Neodymium magnets**

Neodynium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

#### Rubberzied front cap

A rubberized front cap provide a totally soft body for wearing comfort.

#### Soft body

The transparent, rubberized headphone body molds itself to the shape of the ear for comfortable listening.

#### **Built-in microphone**

The built-in microphone lets you easily switch from music listening to taking phone calls - easily, so you'll always stay connected with what matter most to you.



© 2016 Koninklijke Philips N.V. Issue date 2016-07-15 All Rights reserved. Version: 1.2.4 Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners. 12 NC: 8670 001 17191 EAN: 69 23410 73228 3 www.philips.com