



Internet Radio

- DAB+
- Spotify connect
- Bluetooth®

TAM2805/10

Super slim. Feature packed.

Short on space? Go big on entertainment. As well as internet radio and DAB+, this slender wall-mountable micro system gives you Spotify Connect compatibility and Bluetooth streaming. You can even connect your CD player or record deck.

Benefits

[Flexible placement.](#) [Attractive design.](#)

- One small system for all your music
- Perfect for smaller spaces
- Slim, wall-mountable design. Or free-standing on a counter
- 2x 2.75" full-range drivers. 10 W maximum output power

[Everything you need](#)

- Easy streaming. Epic listening
- Bluetooth. Stream, music, podcasts, and more
- Internet radio. DAB+/FM digital radio. Up to 20 presets

Features

[One small system for all music](#)

Looking for something to listen to? This micro system gives you crackle-free digital or internet radio from thousands of stations around the world. You can stream music, podcasts, and more via Bluetooth, and audio-in takes care of wired sources.

- Spotify Connect. Use a mobile device as a Spotify remote

[Fill the room with tunes](#)

- Convenience and control
- Alarm. Wake to your favorite radio station, or a tone
- 2.4 in color TFT display. Included remote
- Main unit dimensions (including stand): 400x220x100 mm

[Perfect for smaller spaces](#)

You can leave this slender micro system free-standing on the included foot, or remove the foot to mount directly onto a wall. Two full-range drivers deliver clear stereo sound.

PHILIPS

Easy streaming. Epic listening

Streaming from Spotify? This Bluetooth internet radio boasts Spotify Connect. Use your mobile as a remote control while the radio streams Spotify's best-quality signal—directly from the Spotify servers. Two full-range drivers deliver clear stereo sound.

Convenience and control

An easy-to-use remote puts key system functions at your fingertips. The colorful display panel shows album art and song information from Spotify Connect, and station logos when you use internet radio or DAB+.

Specifications

[field not found 'disclaimer_text']

Sound

Maximum output power (RMS)	10W
Sound enhancement	digital sound control bass reflex speaker system Dynamic Bass Boost
Sound mode	Pop Jazz Rock Classic Flat
Volume Control	Digital up/down
Frequency response	63-20000 Hz
Speaker impedance	6 ohm

Loudspeakers

Number of sound channels	2.0
Driver configuration	Full range
Number of full range drivers	2
Full range driver diameter	2.75"

Tuner/Reception/Transmission

Tuner type	Digital
Tuner bands	FM DAB/DAB+ Internet Radio
Antenna	FM antenna (75 ohm)
Station presets	20 FM, 20 DAB
RDS	Yes.

Connectivity

WiFi	802.11 a/b/g/n
Bluetooth profiles	A2DP AVRCP
Bluetooth range	10M (free space)
Bluetooth version	4.2
Audio in	3.5mm
Headphone jack	1x 3.5mm
Smart Home	Spotify Connect
DLNA Standard	n.a.

Convenience

Clock update	DAB / Internet radio
Display screen type	2.4" TFT
Display Enhancements	Brightness Control

Alarm

A handy alarm function makes this slender micro system perfect for bedrooms. Wake up smiling to your favorite radio station. Or go for a simple alarm tone.

Alarms	Yes, Buzzer, Internet radio, DAB, FM
No. of alarms	2
Sleep timer	Yes
Remote Control	Yes

Design

System components	Main unit
Wall mountable	Yes

Compatibility

Smartphone/tablet APP control	No
-------------------------------	----

Power

Adaptor type	AC external
Power supply	110-240V, 50/60Hz

Accessories

Included accessories	AC power adaptor FM antenna Remote Control 2 x AAA Batteries Wall mounting bracket Quick start guide Warranty Leaflet
----------------------	---

Dimensions

Main Unit (W x H x D)	400 x 220 x 110 mm
Main Unit Weight	1.71 kg

Packaging dimensions

Depth	15.6 cm
EAN	48 95229 10777 9
Gross weight	2.807 kg
Height	31.5 cm
Nett weight	1.707 kg
Tare weight	1.1 kg
Number of products included	1
Packaging type	Box
Type of shelf placement	Laying
Width	45.5 cm



data subject to change
2023, July 21

Version: 4.0.2
EAN: 4895229107779

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com