

Philips
MP3 Mini Hi-Fi System



FWM397

Enjoy MP3 music in rich sound & great connectivity

with Rip Plus

For unlimited music enjoyment, the FWM397 offers a 3-CD changer, 30-hours non-stop playback and ability to rip all your music - from CDs, tuner and Karaoke- directly to a USB device. Plus, Max Sound and Dynamic Bass Boost ensure great sound

Multiple source MP3 music

- Compatible with WMA and MP3 CDs
- MP3 Link for portable music playback
- Play back songs from USB device
- Rip music from CDs, radio and karaoke onto USB device

Powerful sound you can hear and feel

- 240W RMS total power
- Digital Sound Control for optimized music style settings
- MAX Sound for instant power boost

Easy to use

- 3-CD changer for WMA/MP3-CD music playback
- Clock, alarm and sleep timer
- Connection for TV or DVD player

Be a singing sensation

- Karaoke for endless singing entertainment

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Rip music onto USB device

Rip music from CDs, radio and karaoke onto USB device



Specifications

Sound

- Total Sound Power (RMS): 240 W
- Output Power: 3200W PMPO
- Sound Enhancement: MAX Sound, Dynamic Bass Boost 3 steps, Digital Sound Control 4 modes, Incredible Surround
- Output power (RMS): 4 x 60W / ch

Loudspeakers

- Main Speaker: 2 way, 5.25" woofer, 2" tweeter, Bass Reflex Speaker System
- Number of Loudspeakers: 2

Audio Playback

- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- USB Direct Modes: Delete, Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop, Program Play
- Disc Playback Modes: Repeat/one/disk/program, Shuffle Play, 40-Track Programmable

Audio Recording

- Recording Media: USB device
- USB recording modes: Instant record, Programmed tracks, Schedule radio program, Single disc, Single track
- USB recording sources: Aux, CD, Tuner, Microphone in

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40

- Tuner Bands: FM, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

Connectivity

- Microphone: Dual Microphone sockets
- Other connections: FM Antenna, MW Antenna
- USB: USB host
- Audio Connections: 3.5mm Line in, RCA Aux in

Convenience

- Alarms: CD Alarm, USB alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Karaoke: MIC volume

Accessories

- Included accessories: FM/MW Antenna, Quick Use Guide, *Flat pin adaptor, AC Power Cord
- Remote control: 36-key with 2xAAA batteries
- Guarantee booklet: Global version
- User Manual: Spanish, B-Portuguese
- Quick start guide: Spanish, B-Portugues
- Cables: MP3 Line in Cable

Dimensions

- Set dimensions (W x H x D): 265 x 310 x 403 mm
- Main speaker dimensions (W x H x D): 249 x 344 x 250 mm
- Packaging dimensions (W x H x D): 1014 x 413 x 316 mm
- Weight incl. Packaging: 15 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-07

Version: 3.0.5

12 NC: 8670 000 36159
EAN: 87 12581 38790 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.