



Register your product and get support at

www.philips.com/support

SHB1900



2015 © Gibson Innovations Limited.

All rights reserved.

This product has been manufactured by, and is sold under the responsibility of Gibson Innovations Ltd., and Gibson Innovations Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.



UM_SHB1900
10_EN_V1.0
WK15373


User manual

PHILIPS

1



Pairing button



2



Pair the transmitter with your Bluetooth device

SHB1900 transmits wireless audio from the traditional AV products, such as TV, Sound system, DVD player, PC etc.

- 1** Connect the audio cable to the audio output port of your AV product such as PC or TV etc. Plug the SHB1900 into any USB port for power.
- 2** SHB1900 will automatically enter pairing mode, indicated by flashing red and blue alternatively.
- 3** When pairing for the first time, SHB1900 will search for Bluetooth audio receiving devices such as Bluetooth headphones or Bluetooth speaker. Make sure your Bluetooth audio receiving device is also in pairing mode at the same time.
 - ↳ SHB1900 will pair with your Bluetooth audio device automatically in about 20 to 30 seconds.
 - ↳ SHB1900 will flash blue every 5 seconds if paired successfully. You may now enjoy listening wirelessly with your headphones or speaker.



Note

- If SHB1900 has been paired with a BT audio device, it will first try to connect to it when powered on. If no connection is established within 30 seconds, it will then enter pairing mode to search for a new device.
- Please read the operating instructions of your BT audio device for the pairing procedure.
- If pairing is not completed within 2 minutes, SHB1900 will exit pairing mode.
- To re-enter pairing mode, press the pairing button or re-plug the SHB1900.