



Philips
Classic micro music system

- 10 W
- Tape

MCM167

Obsessed with sound

Relax with great music

Delight yourself in fantastic sound from the truly compact and stylish Philips classic micro music system. Enjoy your favourite MP3-CD music and USB Direct playback richly enhanced by powerful Dynamic Bass Boost.

Multiple sources for more choices

- Play MP3/WMA-CD, CD and CD-RW
- FM digital tuning to preset up to 20 stations
- Cassette deck with auto stop

Quality sound performance

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound

Enrich your sound experience

- 2 x 5 W RMS/2 x 10 W music power/400 W PMPO

PHILIPS

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output power: 2 x 5 W RMS / 20 W music power
- Sound enhancement: Dynamic Bass Boost, digital sound control 4 modes
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3" woofer

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/programme
- Cassette deck technology: mechanical

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording, automatic recording level

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- Loader type: top
- Display type: LCD display
- Backlight colour: Blue

Accessories

- Remote control
- Others: FM/MW antenna, Quick start guide, User Manual
- User Manual: multi-lingual
- Guaranteed: Worldwide Guarantee booklet

Dimensions

- Gross weight: 5.1 kg
- Main speaker dimensions (W x D): 134 x 153 mm
- Main speaker height: 233 mm
- Main unit depth: 209 mm
- Packaging width: 370 mm
- Main unit height: 231 mm
- Packaging height: 270 mm
- Main unit width: 147 mm
- Packaging depth: 326 mm

Power

- Power supply: 220 - 240 V



Issue date 2013-05-10

Version: 2.0.4

12 NC: 8670 000 42976
EAN: 87 12581 44873 8

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com