

Philips  
DVD home theater system



HTS3565



## Powerful surround, high definition video

with powerful compact speakers

Powerful surround sound and high definition pictures delivered by this elegant system provide unbeatable home entertainment. Enjoy sharp pictures with 1080p HDMI upconversion, as well as playback from portable media players and USB sticks.

### Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive

### Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- DoubleBASS for an extended, deep bass experience
- DTS, Dolby Digital and Pro Logic II surround sound
- Clear Voice for more audible vocals in movies and music
- Fullsound™ to bring your MP3 music to life
- Karaoke Scoring for fun and exciting song contests at home

### Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

### Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote

# PHILIPS

# Highlights

## HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

## Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

## DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by

processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like

standby and play can now be carried out with absolute ease.

## Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

## Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan

## Sound

- Output power (RMS): 4x125W, 2x250W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180-14000 Hz
- Signal to noise ratio: >65 dB
- Sound System: DTS, Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Rock, Classic, Concert, Drama, Lounge, Gaming, Sports

## Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: MP3, WMA
- Playback Media: DVD+R/+RW, CD-R/RW, DVD-R/-RW
- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, CD-R/RW, DVD-R/-RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

## Tuner/Reception/Transmission

- No. of preset Audio Channels: 40
- Tuner Bands: FM

## Connectivity

- Front / Side connections: Hi-Speed USB, MP3 Line-in, Microphone input 3.5mm jack
- Rear Connections: HDMI output, Component Video output, S-Video out, Composite video (CVBS) output, AUX in, FM Antenna, Easy-Fit Speaker Connectors, Digital coaxial in

## Power

- Power supply: 120/230VAC, 50/60Hz
- Standby power consumption: < 1 W
- Power consumption: 180 W

## Loudspeakers

- Satellite speaker drivers: 3" full range woofer

- Satellite speaker impedance: 6 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded, 3 way
- Center speaker drivers: 1 x 2" tweeter, 2 x 2.5" woofers
- Center speaker impedance: 3 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 8" high efficiency woofer
- Subwoofer impedance: 3 ohm
- Subwoofer freq range: 40-150 Hz
- Subwoofer type: Passive

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, Quick start guide, User Manual, World Wide Warranty leaflet, Power cord

## Dimensions

- Set dimensions (W x H x D): 435 x 58 x 360 mm
- Set weight: 4.04 kg
- Surround Speaker dimensions (W x H x D): 103 x 203 x 71 mm
- Surround speaker Weight: 0.54 kg
- Center speaker dimensions (W x H x D): 440 x 105 x 75 mm
- Center Speaker Weight: 1.39 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 5.08 kg
- Packaging dimensions (W x H x D): 555 x 310 x 515 mm
- Weight incl. Packaging: 14.5 kg

## Outer Carton

- Gross weight: 14.55 kg
- Outer carton (L x W x H): 55.5 x 51.5 x 31 cm
- Nett weight: 12.3 kg
- Tare weight: 2.25 kg
- EAN: 87 12581 38943 7
- Number of consumer packagings: 1

## Packaging dimensions

- Packaging dimensions (W x H x D): 55.5 x 31 x 51.5 cm
- Gross weight: 14.55 kg
- Nett weight: 12.3 kg
- Tare weight: 2.25 kg
- EAN: 87 12581 38943 7
- Number of products included: 1
- Packaging type: Carton

## Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg



Issue date 2014-02-11

Version: 5.0.7

12 NC: 8670 000 36336  
EAN: 87 12581 38943 7

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)