



Philips
Cordless telephone

DECT3112B

Ease of use

With its mobile look and its wide range of functions, the DECT 311 is both trendy and convenient and is the perfect phone that answers your everyday need.

Experience best sound quality

- CS² Crystal Sound System improves message intelligibility
- Talk on the phone without holding the handset
- Polyphonic ringtones for a more natural and realistic sound

Benefit from easy-to-use technology

- Pilot key & carousel menu navigates in a menu-in-cycle form
- Display for numbers, letters, icons and drawings
- Clock alarm timer

Multi-pack for ultimate convenience

- Use 2 handsets in separate rooms to transmit noises
- Conference call shares a conversation on several handsets
- Free intercom - Free internal calls between handsets

PHILIPS

Specifications

Picture/Display

- Backlight: No
- Diagonal screen size - tele: 4.0 cm
- Effective viewing area: 31.5x21
- Lines of text: 4

Sound

- Handset ringers: Polyphonic
- Volume Control: digital

Convenience

- Auto out of range warning
- Base Station keys: Paging key
- Battery charging indication
- Battery full indication
- Battery low indication
- Call Management: Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Microphone mute, Missed Calls, Received Calls
- Carousel Icons: Phonebook, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Drop proof: 120 cm
- Ease of Use: Hands free mode, Hot Keys, Keypad Lock
- Function: Do not disturb ringer mute, Call cost, Alarm clock, Babysit function, Microphone mute, Conference call, Chain dialling, Direct to Do Not Disturb mode, Short cut keys, Keypad lock, Free handset to handset call
- Handset Keys: Line, Pilot key, Cancel / Recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Lines of text: 4
- Multi handset capability: Up to 6 handsets
- VIP group with own melody: Yes, 3 groups
- Volume control

Accessories

- AC/DC Adaptor
- Batteries: 2 x AAA
- Cables: RJ 11 cable
- User Manual

Related Products

- Package contents: Handset, Base, 2 AAA NiMH Batteries, Telecom Line Cord, Power adapter, User Manual, Warranty leaflet, Sticker

Green Specifications

- Chemical composition: Nickel-Metal Hydride

- Eco Designed
- Halogen-free housing
- Packaging material: Carton
- Packaging type: Giftbox
- PVC-free product and cables
- User manual: Recycled paper

Dimensions

- Antenna: Integrated
- Base dimensions: 118x130x60
- Base weight: 180g
- Form Factor: Semi lying on base station
- Handset color: ebony
- Handset dimensions: 120mm
- Handset weight: 100g
- Packaging dimensions (W x H x D): 262 x 90 x 217 mm
- Relative humidity (operation): up to 95% at 40°C
- Relative humidity (storage): up to 95% at 40°C
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C

Power

- Ambient temperature: 5 °C to 40 °C
- Battery Type: NiMH
- Charging time: 14 hours hr
- Kind of Battery: Rechargeable
- Number of batteries: 2
- Power supply base station: 230V
- Radio RF power: <250mW
- Standby time: 200 hours
- Talk time: up to 15 hours

Network Features

- Antenna: Fast Selection Technology, Integrated on base, Integrated on handset
- Compatible: GAP, PABX
- Dialing: Tone, Pulse

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting
- Operators services phonebook

Memory Capacity

- Name & number shared phonebook: 50
- SMS storage capacity: 15
- Call log entries: 10

Highlights

CS² Crystal Sound System

Philips' unique Crystal Sound System (CS²) audio technology improves the sound quality of Philips DECT phones. CS² audio quality is demonstrably better than competitive DECT products and brings with it distinct benefits.

Handsfree on Handset

The handsfree speaker phone lets you hold a conversation while your hands are busy with something else and wherever you are. With both the speaker and the microphone in front of the handset, it is just like talking face to face with your correspondent.

Polyphonic ringtones

A polyphonic ringtone means that the phone can play many tones simultaneously, so that an accurate musical performance is possible, and when played through the phone's speaker these polyphonic ringtones sound like real music.

Pilot key & carousel menu

The pilot key navigation system allows easy navigation and settings. The pilot key is a roller on the left side of the phone that can be scrolled up and down and pressed in the middle. It commands the Carousel menu which is a circular loop of menu icons displayed on the screen.

Full graphic display

This type of displays makes it easier to use your phone, thanks to the good quality and legibility of the characters. It also gives you more freedom in communication from your home. Now you can combine text with images or numbers, when sending an SMS for example.

Clock alarm timer

Clock alarm timer

Baby-sit function

Worried about your baby not sleeping? No need to constantly go and check in his bedroom. The baby-sit mode allows you to keep an ear on him wherever you are in the house.

Conference call function

Thanks to the conference call, there is no need to travel to meet people. Especially useful in a professional environment where several work stations are connected to the same base station, the conference call allows, for example, two colleagues from Paris to communicate with a colleague in China. A conference call allows two handsets to share the same external phone conversation in such a manner that each handset is able to communicate with the two others.

Free intercom

No need to stop what you are doing and go to give the handset to your son when his friend calls: you can freely and easily call the handset in his bedroom and transfer the call.



Issue date 2014-02-10

Version: 2.0.4

12 NC: 9961 400 02775
EAN: 87 10895 83665 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com