

Philips
Mini Hi-Fi System

MP3

FWM730

wOOx Technology

Hear the Bass, Feel the Difference!

For those who value technology that enhances experiences, FWM730 has it all. Immerse yourself in the power of wOOx Technology and fully appreciate your favorite MP3 music in dynamic and rich sound.

Powerful sound you can hear and feel

- Class 'D' digital amplifier for quality sound performance
- Front firing wOOx Technology speakers
- 2×150 W RMS/ 2×300 W music power/4000W PMPO

Longer listening, greater enjoyment

- 30 hours of MP3-CD music playback
- 3-disc changer for convenient multi-disc playback
- Dual Logic Tape Deck with auto replay

Ready for gaming

- · Gameport connection to your game console
- Game Sound modes for different types of games
- MIX-IT for mixing the game sound with your favorite music



Specifications

- Output Power: 2 x 300W music power
- · Sound Enhancement: Class "D" Digital Amplifier, wOOx technology, Incredible Surround, Digital Sound Control, Virtual Ambience Control, MAX Sound, MIX-IT

Loudspeakers

· Main Speaker: 3 way, Bass Reflex Speaker System, 6.5" woofer, wOOx Bass Radiator, 2" tweeter, Piezo, Speaker grilles detachable

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Disc Playback Modes: Change 2 discs while playing 1, Fast Forward/Backward, Next/Previous Track Search, Repeat/one/all/program, Repeat/one/disk/ program, 99-Track Programmable
- Cassette Deck Technology: Logic
- · Number of decks: 2
- · Cassette Playback Modes: Full Auto Stop, Autoreverse, Electronic Speed Control

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level

Tuner/Reception/Transmission

- Auto digital tuningTuner Bands: FM Stereo, MW, LW
- Tuner Enhancements: Auto Store, Easy Set (Plug &



- Station presets: 40
- RDS: Station Name, RDS Clock Set, Radio Text, Program Type, News

Connectivity

- · Aux in: Line in, Gameport
- · Headphone: 3.5 mm
- Other connections: Composite video (CVBS) out, FM Antenna, MW Antenna

Convenience

- · Alarms: CD Alarm, Radio Alarm, Sleep timer, Wake to favourite track
- · Clock: On main display
- · Display Type: FTD
- Eco Power Standby: 1 watt
- · Indications: DIM mode, track, file name, time, date, Cd functions, artis name, album number, album name

Accessories

- Remote control: 32-key with 2xAA Batteries
- Included accessories: AC Power Cord, FM/MW Antenna

Dimensions

- Set dimensions (W \times H \times D): 265 \times 322 \times 384 mm
- Main speaker dimensions (W x H x D): 240 x 358 x 238 mm
- Packaging dimensions (W x H x D): 510 x 412 x 624 mm
- Weight incl. Packaging: 20.5 kg

- Standby power consumption: < 1W
- Power supply: 50/60 Hz, 110-240V

Highlights

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Front firing wOOx Technology Front firing wOOx Technology speakers

2x150W RMS/2x300W music power 2 x 150W RMS/ 2 x 300W music power/4000W

30 hours of MP3-CD music MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

Dual Logic Tape Deck

Dual Logic Tape Deck with auto replay

Gameport connection

Gameport connection to your game console

Game Sound modes

Game Sound modes for different types of games

MIX-IT for mixing game sound

MIX-IT for mixing the game sound with your favorite



Issue date 2014-02-10

Version: 3.0.4

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 100 12182 EAN: 87 10895 85448 1

www.philips.com