

Philips DVD player

DivX playback

**DVP5900** 

# See, hear, play everything with HDMI

Be impressed with this Philips DVD player with HDMI digital video and audio connection. Step into another home entertainment arena as you immerse yourself with High Definition video (720p / 1080i).

# Unrivalled video performance

- HDMI digital output for easy connection with only one cable
- Video Upscaling for improved resolution of up to 1080i
- High definition JPEG playback for images in true resolution

### **Enrich your movie experience**

- · Progressive Scan component video for optimized image quality
- 192kHz/24 bit audio DAC enhances analogue sound input

### Play it all

- Movies: DVD, DVD+R/RW, (S)VCD, DivX, MPEG4
- Music: CD, MP3-CD, CD-R/RW & Windows Media  $^{\text{TM}}$  Audio
- Photos: Picture CD (JPEG)



# Highlights

# **HDMI** for simple AV connection

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backward-compatible with (Digital Video Interface) DVI.

### Video Upscaling up to 1080i

With Video Upscaling you can increase the resolution of SD (Standard Definition) video signals that DVD uses to HD (High Definition) so you'll be able to see more details thanks to a sharper, more true-to-life picture. The resulting HD video output signal can be fed to an HD display through HDMI (High-Definition Multimedia Interface).

### High definition JPEG playback

High definition JPEG playback lets you view your pictures on your television in resolutions

as high as two megapixels. Now you can view your digital pictures in absolute clarity, without loss of quality or detail - and share them with friends and family in the comfort of your living room.

### **Progressive Scan**

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

### 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original

analogue sound wave form, giving a much richer audio reproduction.

### Multi-format Movies-DivX, MP4

Multi-format playability allows you to play most disc formats for maximum compatibility and viewing pleasure.

### Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

### Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

















# Specifications

### Picture/Display

- D/A converter: 10 bit, 54 MHz
- Picture enhancement: Progressive scan, Video upscaling, Video upsampling

#### Sound

- D/A converter: 192kHz/24-bit
- Signal to noise ratio: 108 dB
- Distortion and Noise (1kHz): 80 dB
- Crosstalk (1kHz): 100 dB
- Dynamic Range (1kHz): 94 dB
- Sound System: Dolby Digital, MPEG2, Stereo
- · Sound Enhancement: Night Mode

### Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/ SVCD, DVD, DVD-RW (Video mode), DVD-R, DVD-Video, DivX, WMA, DVD+R/+RW
- Compression formats: MPEG1, MPEG2, MPEG4, XviD, DivX 3.11, DivX 4.x, DivX 5.x

# **Audio Playback**

- Playback Media: CD, MP3-CD, WMA, CD-R/RW
- Compression format: Dolby Digital, MP3, PCM, Windows Media™ Audio
- MP3 bit rates: 32 256 kbps

# **Still Picture Playback**

- Playback Media: Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, High Definition Resolution

### **Connectivity**

- Other connections: HDMI out
- Audio Output Analog: Stereo (Red/White cinch)
- Audio Output Digital: Coaxial (cinch)
- Video Output Analog: Component RGB (SCART), Composite CVBS (on SCART), Component Y Pb Pr (cinch), Composite CVBS (yellow cinch)

### **Convenience**

 On-Screen Display languages: English, Mexican Spanish, Canadian French

#### Power

- Power supply: 100-240VAC, 50/60Hz
- Standby power consumption: < 3W

### Accessories

- Cables: None
- Remote control: 3141 017 90221
- User Manual: English, Canadian French, Mexican Spanish
- Included batteries: 2x Longlife AA

### **Dimensions**

- Packaging dimensions (W  $\times$  H  $\times$  D): 489  $\times$  84  $\times$  405 mm
- Weight incl. Packaging: 3.7 kg
- Set dimensions (W x H x D): 435 x 48 x 310 mm
- Set weight: 1.9 kg
- Weight incl. Packaging (lb): 8.1



Issue date 2014-02-06

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 3.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8622 810 12788 UPC: 0 37849 96733 1

www.philips.com