

Philips
DVD player



DVP4060



Fits anywhere, goes everywhere

Be in total empowerment to enjoy sharp, crystal-clear picture and sound quality movies and music wherever and whenever you desire. It's your home entertainment - at your control.

Great audio and video performance

- Progressive Scan component video for optimized image quality
- High quality outputs for analog and digital audio
- Smart Sound optimizes audio settings

Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Photos: Picture CD (JPEG)

Fits everywhere, goes anywhere

- Compact design
- Quick and easy set-up for no-fuss installation

PHILIPS

Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

Video Playback

- Playback Media: CD-R/CD-RW, CD, DVD, DVD-R/-RW, DVD+R/+RW, Video CD/SVCD, DVD-Video
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- Compression format: MP3, WMA, PCM, Dolby Digital
- MP3 bit rates: 32 - 256 kbps

Still Picture Playback

- Playback Media: DVD-R/-RW, DVD+R/+RW, CD-

- R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow, Flip photos

Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Brazilian Portuguese, Spanish

Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W

Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Remote Control, World Wide Warranty leaflet, User Manual, Power cord, VDE to 2-pin Flat Adaptor

Dimensions

- Set dimensions (W x H x D): 226 x 48 x 209 mm
- Packaging dimensions (W x H x D): 277 x 88 x 292 mm

Highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Smart Sound

Smart Sound provides the optimal sound settings for ultra bass, bass, treble and balance so that you can get the best entertainment experience.

Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.



Issue date 2014-02-06

Version: 1.0.5

12 NC: 8670 000 32604
EAN: 87 12581 35347 6

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com