



Philips  
wireless portable speaker

Bluetooth®  
White



BT51W

## Make room to dance

Take your tunes out with the Bluetooth speaker that fits in your pocket. This tiny speaker gives you six hours play time and crisp sound, even at maximum volume. The wireless range is 10 m. Plenty of room to dance across the room.

### **Tiny speaker. Crisp sound out loud.**

- 1.5" full-range speaker. Crisp, clear sound
- Anti-clipping function. Turn it up without distortion
- 5 hours play time

### **Always ready to go**

- Really light. Weighs just 90 g
- Really small. 6.1x6.1x7.6 cm
- Up to 10 m wireless range

### **Easy to pair. Easy to charge.**

- Bluetooth is ready to pair with power-on
- USB charging. Micro USB cable included

# PHILIPS

wireless portable speaker  
Bluetooth® White

# Specifications

## Accessories

- Included accessories: Quick install guide, World Wide Warranty leaflet
- Cable: USB charging cable

## Compatibility

- other Bluetooth-enabled device
- work with: up to iOS 10.2, Bluetooth 4.2 or below

## Connectivity

- Bluetooth profiles: A2DP, AVRCP, HFP
- Bluetooth range: Line of sight, 10M or 30FT

## Design and finishing

- Color: White

## Sound

- Output power (RMS): 2W
- Sound System: Mono

## Power

- Battery type: lithium polymer (built-in)
- Operating time on battery: 5 hr

## Dimensions

- Packaging dimensions (WxDxH): 8.1 x 9.5 x 11.3 cm
- Product dimensions (WxDxH): 6.1 x 6.1 x 7.6
- Product weight: 0.135 kg
- Weight incl. Packaging: 0.18 kg

BT51W/00

# Highlights

## Tiny speaker. Crisp sound.

Weighing just 90 g, you'll barely notice you're carrying this tiny speaker. The 1.5" full-range driver delivers crisp, clear sound even when you turn the volume up.

## 5 hrs play time. USB charging.

The battery gives you 5 hours play time from a full charge. Charging takes less than 3 hours, and is easy via the included micro USB cable.

## Bluetooth connectivity

Pairing with your Bluetooth device is simple. Just power on the speaker and it's ready to pair. The wireless range is 10 m.

## Anti-clipping function

Anti-Clipping lets you play music louder and keeps its high quality, even when the battery is low. It accepts a range of input signals, from 300mV to 1000mV and keeps your speakers safe from damage by distortion. This built-in function monitors the musical signal as it goes through the amplifier and keeps peaks within the amplifier's range, preventing the audio distortion caused by clipping without affecting loudness. A portable speaker's ability to reproduce musical peaks decreases along with battery power, yet anti-clipping reduces peaks caused by low battery, keeping music distortion free.



Issue date 2021-02-03

Version: 7.1.3

12 NC: 8670 001 59295  
EAN: 69 51613 99572 3

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)