



Philips
Micro music system

Bluetooth

USB port for play/charging
DAB+

BTB8000

Give your music room to breathe

Whatever you love to listen to, set it free with 150 W of rich, room-filling sound. Bass-reflex loudspeakers ensure deep low-end response, from your favourite CDs to your chill-out playlist. Audio-in and USB let you connect external sources.

Deep, powerful sound

- 2-way bass-reflex loudspeakers. Full, powerful low tones
- 5.25" woofer and dome tweeter
- 150 W maximum output power
- Bass and treble control knobs. Volume meters

All your music

- CD player. DAB+/FM digital radio
- Digital tuning with up to 20 presets
- Bluetooth wireless music streaming
- USB. Instantly connect music devices. Charge smart devices
- Audio-in. Connect to almost any source

Fill the room with tunes

- Mains-powered (AC-in). Remote control
- Main unit dimensions: 240 x 145 x 230 mm
- Speaker dimensions: 241 x 261 x 173 mm

PHILIPS

Micro music system
Bluetooth USB port for play/charging, DAB+

BTB8000/12

Highlights

All your music

This smart, compact music system lets you stream playlists and more with rich, room-filling sound. Dust off the classics in your CD collection thanks to a CD player that also plays MP3 CDs and recorded CDs. The digital radio tuner delivers crystal-clear reception and you can set up to 20 presets for your favourite DAB+ or FM stations.

Rich sound with full bass

The bookshelf-style loudspeakers give you crisp high ends from dome tweeters and powerful bass from 5.25" woofers and bass-reflex ports. 150 W maximum output ensures you'll fill almost any room with your favourite

tunes. The fabric speaker covering can be removed for a more modern look.

Old school, meet new school

With its clean lines, brushed aluminium front and twin illuminated volume monitors, the central unit of this micro system recalls classic hi-fi designs. The textured volume-control dial and bass and treble knobs add a satisfying analogue feel to operation. Buttons on top of the unit control pairing, source selection and playback/tuning.

Fine-tune every classic

Tweak the treble and bass settings just how you like with the control knobs on the central

unit. Paired analogue volume meters let you check the input signal level for the best sound reproduction. Simply change the output volume on your device until the needle stays away from the red peak area.

At home in your home

This AC-powered micro system looks great in any room. The Bluetooth wireless range is 10 m, and you can charge a smart device via the USB port when the system is in standby mode. An easy-to-use remote puts key system functions at your fingertips—so you can control the mood without breaking the mood.



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Sound

- Maximum output power (RMS): 150 W
- Sound Enhancement: Treble and Bass Control

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- RDS: Programme Type, Station Name, Radio Text
- Station presets: 20 FM, 20 DAB
- Antenna: FM antenna, FM antenna (75 ohm)
- DAB/DAB+: Band III, Info display, Menu

Loudspeakers

- Main Speaker: 2-way, Dome tweeter, 5.25" woofer

Connectivity

- 3.5 mm stereo line in: Audio in
- Rear Connections: DAB antenna
- Bluetooth: Bluetooth V2.1
- Bluetooth profiles: A2DP, AVRCP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display Type: VFD display
- Eco Power Standby: 0.5 watt
- Indications: DIM mode
- Display type: VFD display
- USB Charging: Max. 2 A

Accessories

- Included accessories: AC Power Cord, FM antenna
- Remote control
- User Manual: Multi-language

Power

- Power supply: 110-240V, 50/60 Hz

Dimensions

- Packaging dimensions (W x H x D):
572 x 350 x 322 mm
- Main unit depth: 240 mm
- Main unit height: 145 mm
- Main unit width: 230 mm
- Main speaker dimensions (W x H x D):
173 x 261 x 241 mm
- Gross weight: 10.7 kg
- Net weight: 8.7 kg



Issue date 2022-05-15

Version: 5.0.10

12 NC: 8670 001 46557
EAN: 69 59033 84811 7

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com