

Philips

CD Soundmachine with Dynamic Bass Boost

MP3

digital tuning cassette

AZ3068

# Enjoy your MP3 & WMA digital music

# with two-way speaker system

Uncomplicated yet comprehensive, this rugged player delivers superb sound performance with quality 2-way speakers. Enjoy your favorite MP3 or WMA-CD, 30 preset FM stations on the digital tuner in enriched sound - anytime, anywhere.

### The ultimate listening experience

- Autostop stereo cassette deck
- · Digital tuning with presets
- 10 hours of MP3-CD or 20 hours of WMA-CD music

### Powerful bass you can hear and feel

- 2-step Dynamic Bass Boost for a deeper bass experience
- 4" full range speakers for powerful sound
- Bass Reflex speakers deliver a powerful, deeper bass

## Easy to use

- · Handy remote control
- Line-in connection
- Stereo headphone socket



### AZ3068/37

# Specifications

#### Sound

- Output power (RMS): 2x4W (Mains power), 2x2W(Battery)
- Sound System: Stereo
- Volume Control: Volume Control rotary/encoder
- Loudspeaker types: 2-way Bass Reflex Speaker
- · Speaker diameter: 4"
- Sound Enhancement: Dynamic bass boost 2 steps

#### **Audio Playback**

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- · Number of decks: 1
- · Cassette Deck Technology: Mechanical

# Tuner/Reception/Transmission

- · Auto digital tuning
- Station presets: 30
- Antenna: FM Antenna
- Tuner Bands: FM, MW

#### **Connectivity**

- · Aux in: Line in
- · Headphone: 3.5 mm

#### **Convenience**

- Display Type: LCD
- Remote control: 20 keys

#### Accessories

 Included Accessories: AC Power Cord, User Manual, Warranty certificate

#### Power

- Mains power
- Battery type: LR20
- Battery voltage: 1.5 V
- Number of batteries: 6

#### **Dimensions**

- Packaging dimensions (W x H x D): 493 x 210 x 314 mm
- Product dimensions (W  $\times$  H  $\times$  D): 435  $\times$  174  $\times$  263 mm
- Weight: 3.3 kg
- Weight incl. Packaging: 4.4 kg













# Highlights

# Handy remote control

Handy remote control

#### **Line-in connection**

Line-in connection

#### 2-step Dynamic Bass Boost

2-step Dynamic Bass Boost for a deeper bass experience

#### **Bass Reflex Speaker System**



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

# MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A singe CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.



Issue date 2009-11-06

Version: 1.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 32731 UPC: 6 09585 14007 3

www.philips.com