

Philips
Wireless speaker

Bluetooth®
10 W Output Power
10 hours of play time

TAVS500



All that jazz

Looks to warm your heart. Sound to move your feet. This large retro-style Bluetooth speaker gives you 10 hours of play time, powerful bass and aux-in to connect to any source. Authentic 1950s detailing adds timeless magic to the mix.

Retro style. Modern performance.

- Vintage wooden cabinet. Period 1950s details
- Brass-toned controls and volume-control knob
- 10 hours of play time
- Aux-in. Connect to almost any source

Tuned for today

- Clear, detailed sound. 3" full-range driver
- Bass-reflex port. Full, powerful low tones
- 10 W output power
- Up to 10 m wireless range

Easy pairing. Easy listening.

- Speaker buttons for play/pause, power/source, Bluetooth
- USB charging. Micro USB cable included
- Dimensions: 180 x 84 x 140 mm
- Weight: 940 g

PHILIPS

Specifications

Sound

- Output power (RMS): 10 W
- Sound System: Mono

Connectivity

- Bluetooth profiles: A2DP, AVRCP, HFP
- Bluetooth range: Line of sight, 10 m or 30 ft
- Bluetooth version: 5
- Audio in (3.5 mm)

Accessories

- Included accessories: World Wide Warranty leaflet, Quick install guide, USB cable for PC charging

Dimensions

- Packaging dimensions (WxDxH): 22.5 x 13 x 17.3 cm
- Product weight: 0.94 kg
- Weight incl. Packaging: 1.405 kg
- Product dimensions (WxDxH): 18 x 8.4 x 14 cm

Power

- Battery type: lithium polymer (built-in)
- Operating time on battery: 10 hr

Compatibility

- other Bluetooth-enabled device
- work with: up to iOS 10.2, Bluetooth 4.2 or below

Highlights

Authentic vintage

This retro-style Bluetooth speaker looks like it's straight out of the 1950s. The vintage wooden cabinet. The brass-toned volume control knob and speaker grille. Details from back when jazz had the edge and rock and roll was just beginning.

10 hours of play time

The battery gives you 10 hours of play time from a full charge. Charging takes around 4 hours and is easy via the included micro USB cable. A simple press of the Bluetooth button gets this speaker ready to pair with your Bluetooth device.

Crisp sound. Powerful bass.

From hip-hop to EDM. Just because this speaker looks jazz doesn't mean it only plays jazz. Whatever you're listening to, the 3" full-range driver delivers clear, detailed sound. A bass-reflex port fills in the low tones, giving you rounded, powerful bass response.

Easy listening

A play/pause button on top of the speaker easily controls your music, while volume up/down is via the retro-style knob. When the speaker is on, press the power button to switch between sources. The wireless range is 10 m: perfect for lazy afternoons in the garden or park.

All your music. Any source.

The 3.5 mm aux-in socket at the back of the speaker lets you connect to almost any external audio source. Turntable, MP3 player, CD player: as long as you have the right cable, you can play your whole library.

