

Philips
CD Soundmachine

**VCD** 

AZ2536

# Ultimate Entertaiment Experience

# with VCD playback and Karaoke

Maximize your entertainment experience with the assertive AZ2536! With an awesome mix of VCD playback and powerful Max Sound, you can totally immerse in music, movies and karaoke – and never leave your room!

## Share your movie and Karaoke experiences

- Video CD2.0 playback with powerful playback control function
- · Karaoke for endless singing entertainment
- PAL/NTSC compatible

# Powerful sound you can hear and feel

- MAX Sound for instant power boost
- Bass Reflex Speaker System delivers a powerful, deeper bass

# Enjoy favorite music from three different sources

- MP3-CD,CD-R/RW compatible
- · Digital tuning with preset stations for extra convenience
- Autostop cassette deck



### AZ2536/12

# Specifications

#### Sound

- Output power (RMS): 2X4W
- · Sound System: Stereo
- Volume Control: rotary

#### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- · Loader Type: Top
- Programmable Tracks: 20

#### Tuner/Reception/Transmission

- · Antenna: AM Antenna, FM Antenna
- · Auto digital tuning
- Tuner Bands: FM, MW

#### **Connectivity**

- Audio output: Stereo Audio (3.5 mm jack) 1x
- · Aux in: Karaoke
- · Headphone: 3.5 mm
- Video Output Analog: Video (3.5mm jack) 1x







#### **Convenience**

- Backlight color: Amber
- Display Digits: 7
- Display Type: LCD

#### Accessories

 Included accessories: AC Power Cord, Audio/ Video cable, User Manual, Warranty certificate

#### **Dimensions**

- Packaging dimensions (W  $\times$  H  $\times$  D):  $560 \times 236 \times 348 \text{ mm}$
- Product dimensions (W x H x D): 520 x 178 x 287 mm
- Weight: 4.1 kg
- Weight incl. Packaging: 6.1 kg

#### Power

- Battery type: LR20
- Battery voltage: 1.5 V
- · Mains power
- Number of batteries: 8

# Highlights

### Video CD2.0 playback

Video CD2.0 playback with powerful playback control function

#### **Karaoke**

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.

#### **PAL/NTSC** compatible

PAL/NTSC compatible

#### **MAX Sound**

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

### **Bass Reflex Speaker System**

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

# MP3-CD,CD-R/RW compatible

MP3-CD,CD-R/RW compatible

# Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

# **Autostop cassette deck**

Autostop cassette deck



Issue date 2011-04-28

Version: 3.0.4

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 101 01406 EAN: 87 10895 82981 6

www.philips.com