

Philips  
Wireless Home Monitor

Monitor anywhere

Wi-Fi  
For smartphone, tablet  
Dual pack



M100G



Watch over your home from your smartphone/tablet

Put your mind at ease

The Philips InSight wireless home monitor allows you to watch over your home when you are away. Setup is easy, giving you instant monitoring from your smartphone/tablet. Push alerts tell you when motion or noise has been detected.

**Stay close to loved ones when you're on the move**

- Wi-Fi enabled for placement anywhere in your home
- Easy-to-use Apple/Android app for free
- Browser-based monitoring using any web browser
- Instant monitoring from your smartphone/tablet

**Secure and easy to set up**

- Magnetic base for easy adjustment of viewing direction
- Extra wall mount for the best possible placement
- Encrypted direct networking for secure connection
- Easy set-up of Wi-Fi-enabled monitor via QR code
- Watch up to 16 monitors with one app on smartphone/tablet

**Alerts via push notifications**

- Built-in noise and motion detection
- Phone alerts when monitor detects noise/motion

**PHILIPS**

# Highlights

## Browser-based monitoring

The InSight wireless home monitor also allows you to find out what's going on at home in real time from your favourite web browser, be it Chrome, Internet Explorer, Safari or Firefox, on a PC or Mac.

## Direction adjustable



The Philips InSight wireless home monitor has a magnetic base that holds the monitor, allowing you to rotate and adjust your monitor to any angle.

## Extra wall mount



In.Sight wireless home monitor comes with a wall mounting bracket. Use it to easily mount your monitor to any wall or ceiling. The base itself pivots and turns, so you can still

reposition the In.Sight wireless home monitor when it is mounted.

## Encrypted direct networking



Philips In.Sight wireless home monitor uses highly secure encryption to provide you with privacy at all times. In.Sight wireless home monitor uses a unique encryption key each time it makes a connection.

## Noise and motion detection



It's impossible to predict when something might happen. The InSight wireless home monitor keeps watch with adjustable noise and motion detection. You will be alerted any time noise or motion is detected.

## Alert notifications

Phone alerts when monitor detects noise/motion

## Easy set-up via QR code

Set-up is simple with the app. The app will generate a QR code for your home Wi-Fi settings. With the QR code, the monitor will automatically pair with your Wi-Fi network, easily and instantly.

## Free Apple/Android app

Easy-to-use Apple/Android app for free

## Instant monitoring

Instant monitoring from your smartphone/tablet

## Watch up to 16 monitors

Watch up to 16 monitors with one app on smartphone/tablet

## Wi-Fi enabled

The In.Sight wireless monitor is a Wi-Fi enabled monitor. It uses your home wireless network to stream live video and audio to your smartphone/tablet. A home monitor that you can set up anywhere you like.



Direction adjustable



Easy set-up



Watch up to 16 monitors



Encrypted direct networking



Noise and motion detection



Alert notifications



PHILIPS



Available on the App Store



ANDROID APP ON Google play

# Specifications

## Lens and Sensor

- Sensor: VGA
- Focus mode: Fixed
- Focus range: 0.4 M to infinity

## Video Quality

- VGA streaming
- Formats: H.264 video compression
- White Balance: Automatic white balance
- Exposure: Automatic exposure control

## Features

- Wi-Fi: 802.11 b/ g/ n (2.4 GHz), 802.11 a (5 GHz) not supported
- Motion detection
- Noise detection
- LED indicator
- Magnetic base: Direction adjustable
- Reset button
- Screw holes: Yes, 1

## Software

- Installation: via App for Android and Apple
- Automatic App update: Yes, for Android and Apple
- Web browser support
- System supported: iOS4.3 or above, Android 2.3 or above
- iPad compatibility: iPad, iPad 2, New iPad, iPad with Retina display, iPad mini
- iPhone compatibility: iPhone 3GS, iPhone 4, iPhone 4S, iPhone 5

- iPod compatibility: iPod Touch 4th generation and up
- Android phone compatibility: Philips recommends Samsung Galaxy 3 performance phones or better

## Accessories included

- Extra wall mount: 2
- USB power adapter: 2
- USB cable: 2, 2.5 m each
- Screws/wall anchors: 6
- Quick Start Guide

## Input and Output

- Microphone: Highly sensitive, Mono
- USB: Mini-USB port

## Minimum Requirements

- Windows: Windows XP, Windows Vista, Windows 7, Internet Explorer 6.0, PENTIUM 4 - 2.8 GHz processor, 1 GB RAM and 64 MB Video RAM
- MAC: MACINTOSH 10.4, MACINTOSH 10.5, MACINTOSH 10.6, MAC 1.66 GHz Intel Core Duo, Safari 1.1

## Dimensions

- Packaging dimensions (W x H x D): 158 x 175 x 76 mm
- Product dimensions (W x H x D): 45 x 95 x 45 mm



Issue date 2014-11-28

Version: 2.0.4

12 NC: 8670 001 05551  
EAN: 08 71258 16945 24

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Viewing live video over your home Wi-Fi network using the In.Sight wireless home monitor is free and unrestricted. Viewing live video remotely (either over an external Wi-Fi network or 3G network) is also free for unlimited sessions, but subject to a limit of 5 minutes per session.

\* Longer remote viewing session times and other premium features are available for purchase from the App. These conditions are subject to change.