



Philips
Cordless phone answer
machine

DECT6172H

Indulge in colour

DECT 6 series is especially designed for people who have a keen preference for performance and quality. Simple and elegant, reflecting an intuitive design and user interface, it is visually appealing to its target audience.

Colour that livens up your phone

- Color display has 6 lines of text and 4K pixel resolution
- na
- na

Ready-to-use answering machine

- Obtain different types of messages for your answerphone
- Easy answer phone control with 7 direct access keys
- Specific outgoing messages for VIP groups.

Duo pack for ultimate convenience

- Use 2 handsets in separate rooms to transmit noises
- Free intercom - Free internal calls between handsets
- Complete phone package including a base and 2 handsets

Benefit from modern, easy technology

- Download ringtones from dedicated sites
- Eatoni predictive text entry simplifies writing SMS messages

PHILIPS

Highlights

Color screen

The color screen adds more fun and excitement by enriching messages and other features. The large color display can show up to 6 lines of text with a 4k pixel resolution. Color also makes your phone easier to use: menus and sub-menus are easily read and icons are easily identified, allowing any desired applications and functions to be located and selected quickly and easily.

White backlight

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark.

Flashing Message Indicator

Downloadable outgoing messages

This function gives the user the possibility to download specific outgoing messages for their answering machine. Simply call the dedicated service provider and select your favourite outgoing message. This message will be recorded on the answering machine by the service provider (country and network dependent).

Easy answer phone control

Easy answer phone control with 7 direct access keys

Specific Outgoing Messages

When you're away or do not wish to be disturbed you can record a different message for each VIP groups. Like this, your friends are not treated the same way than your professional calls.

Baby-sit function

Worried about your baby not sleeping? No need to constantly go and check in his bedroom. The baby-sit mode allows you to keep an ear on him wherever you are in the house.

Free intercom

No need to stop what you are doing and go to give the handset to your son when his friend calls: you

can freely and easily call the handset in his bedroom and transfer the call.

Plug & Play pack - 2 handsets

The unique soft touch feel ensures that the phone lies perfectly within your hand and increases comfort while calling.

Ringtone download

This function offers the possibility to personalize your phone by downloading ringtones. Simply call the dedicated service provider and select your favourite song. An SMS is sent to you, together with the attached melody. You can select this melody as any other ringtones (country and network dependent).

Eatoni text editor

Eatoni's LetterWise is an easy-to-use text-entry solution requiring just 1.16 taps per correct letter. It makes typing on phone keypads as comfortable, fast, and accurate as using a typewriter keyboard. It is unique among predictive text entry solutions in its ability to easily handle the entry of abbreviations, names, addresses, and URLs.

Personal mail boxes

Children at a certain age need some privacy at home when sending SMS to their friends. But paying for several mobile phones quickly gets very expensive. DECT phones provide up to 9 personal SMS mail boxes which can be protected by a PIN code - SMS can stay private despite collective phone usage. The user must tell his correspondents his mail box number so that they can send short messages directly to this personal mail box. Sending a SMS from a personal mailbox makes it easy for the addressee to reply directly to this mailbox without having to remember the mailbox number.

Loudspeaker on base & handset

Loudspeaker on base & handset for message and conversation I

Specifications

Picture/Display

- Display backlight: White
- Display colors: 4096 colors
- Display technology: Liquid Crystal Display
- Effective viewing area: 34 x 25
- LCD panel type: 65 x 108 pixels

Connectivity

- Headset: Via Jack Connector (Handset)

Convenience

- Multi base capability: Up to 4 bases
- Multi handset capability: 8

Network Features

- Compatible: GAP

Operator Requirements

- SMS
- Name and Caller ID
- Caller ID on call waiting

Answering Machine

- Recording time capacity: 40 min
- VIP outgoing message
- Call screening

Memory Capacity

- Name & number shared phonebook: 250 names and numbers
- SMS storage capacity: 60
- Call log entries: 40



Issue date 2016-12-27

Version: 2.0.3

12 NC: 9961 400 03715
EAN: 87 10895 86394 0

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com