

Detailed specifications webcam SPC620NC



Table of Contents

1	DISPLAY MOVING VIDEO RESOLUTION	2
2	DISPLAY STILL IMAGE RESOLUTION	2
3	DETAILED DIMENSIONS	2
4	POWER CONSUMPTION	3
5	OVERALL SYSTEM REQUIREMENTS	3
6	LENS SPECIFICATIONS	4
7	MICROPHONE SPECIFICATIONS	4
8	SOFTWARE (DRIVER, FIRMWARE, PC SOFTWARE)	4

1 Display moving video resolution

Output res.	Pixels (H x V)	Frame rate	Terms	Remark
1.3 MP	1280 x 960	30, 20, 15, 10, 5 fps	Required	SW up sampling
VGA	640 x 480	30, 25, 20, 15, 10, 5 fps	Required	Optical resolution
CIF	352 x 288	60, 30, 25, 20, 15, 10, 5	Required	SW down sampling
		fps		
SIF	320 x240	30, 25, 20, 15, 10, 5 fps	Required	SW down sampling
QCIF	176 x 144	30, 25, 20, 15, 10, 5 fps	Required	SW down sampling
QSIF	160 x 120	30, 25, 20, 15, 10, 5 fps	Required	SW down sampling

2 Display still image resolution

•	•	•	
Output res.	Pixels (H x V)	Terms	Remark
5.0 MP		Required	SW up-scaling (interpolation)
4.0 MP		Required	SW up-scaling (interpolation)
3.0 MP		Required	SW up-scaling (interpolation)
2.0 MP		Required	SW up-scaling (interpolation)
1.3 MP		Required	Optical resolution
SVGA	800 x 600	Required	SW up-scaling (interpolation)
VGA	640 x 480	Required	SW down sampling
CIF	352 x 288	Required	SW down sampling
SIF	320 x240	Required	SW down sampling
QCIF	176 x 144	Required	SW down sampling
QSIF	160 x 120	Required	SW down sampling

3 Detailed dimensions

Part	Width	Height	Depth
Lens	32 mm	32 mm	16 mm
Body	40 mm	56 mm	12 mm
Stand (folded)	39 mm	30 mm	88 mm
Stand clamp capacity	-	-	10 - 70 mm

4 Power consumption

The SPC 620NC is USB 2.0 bus powered		
Operation mode	< 150mA (V-Bus)	
Stand-by mode	< 50mA	
Suspend mode	< 500uA	

5 Overall system requirements

Interface Operating systems	USB 2.0 certified and USB 1.1 backwards compatible • Microsoft Windows® Vista Home Basic, -Home Premium, -Ultimate, -Business, -Starter, Windows XP Professional, -Home, Windows XP 64 bits, Media Centre Edition.
Minimal system requirements	For a Microsoft Windows-based PC: • Microsoft Windows® Vista Home Basic, -Home Premium, -Ultimate, -Business, -Starter, Windows XP Professional, -Home, Windows XP 64 bits, Media Centre Edition. Pentium 500 MHz or higher processor • 128 MB of RAM • 200 MB of available hard disk space • USB 2.0 or USB 1.1 port • CD drive
Recommended system requirements	For a Microsoft Windows-based PC: • Microsoft Windows® Vista Home Basic, -Home Premium, -Ultimate, -Business, -Starter, Windows XP Professional, -Home, Windows XP 64 bits, Media Centre Edition. Pentium 1.5 GHz or higher processor • 512 MB of RAM • 200 MB of available hard disk space • USB 2.0 or USB 1.1 port • CD drive
Application software compatibility	Microsoft NetMeeting 5.0 Microsoft MSN Messenger Yahoo! Messenger AOL Messenger Skype Arcsoft VideoImpression 2.0 Adobe PhotoShop 5.0 Arcsoft PhotoImpression 3.0 Microsoft's Windows XP sound recorder VLounge Advanced from Arcsoft Advanced control panel

6 Lens specifications

F: 2.4
Construction: Non spherical surface plastic/glass
Distortion: <1.0%
Optical format: 1/4"
Material: Non spherical surface plastic/glass
Depth of field: 0.8 m ~ infinity
Focus distance: 1 cm ~ Infinity adjustable
Focus default: 60 cm
Focussing: Will be done by rotation
Resolution: 90/90lp/mm on axis and off axis
Depth of field @ 1.2m focus point: 80 cm ~ infinity
Wave length: λ=400-670 nm (colour)
Lateral axial chromatic aberration: Centre <3 μm and
diagonal <9 μm
Relative illumination: >80 %
IR Cut-off Filter: 670nm ± 10 nm
Flare ratio: <4% according to ISO 9358
Mount: M12 x 0.5P
Shading: 30%

7 Microphone specifications

	Sensitivity: $-34 \pm 3dB (0dB = 1V / 0.1Pa.1kHz)$		
	Directivity: Omni-directional		
Frequency: 40 - 16000 Hz			
	S/N ratio: 58dB (minimum)(A-curve at 1kHz.0.1Pa)		

8 Software (driver, firmware, PC software)

Philips VLounge Generic application software	version V1.0.0.75 (2007-07-17) or higher are
Available languages	required in order to enjoy full product
Chinese (Simplified), Chinese (Traditional),	functionality
Czech, Dutch, English, French, German, Greek,	
Hungarian, Italian, Japanese, Korean, Polish,	
Portuguese, Romanian, Russian, Slovak,	
Spanish, Swedish, Turkish	
Drivers (XP, Vista)	version v1.61.1.5790 (2007-10-11) or higher
Available languages	are required in order to enjoy full product
Chinese (Simplified), Chinese (Traditional),	functionality
Czech, Dutch, English, French, German, Greek,	
Hungarian, Italian, Japanese, Korean, Polish,	
Portuguese, Romanian, Russian, Slovak,	
Spanish, Swedish, Turkish	