

Philips DVD soundmachine **MP3-CD** Tape



# Enjoy your favorite DVD movies, music and photos

Enjoy your favorite movies, music and even photos on the TV with this all-in-one Philips DVD soundmachine. Powerful stereo music and sound effects are delivered through the Bass Reflex speaker system with two 10.2 cm/4" full range speakers.

# **Everything you need**

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- FM tuner for radio enjoyment
- Autostop cassette deck

# Rich and clear sound

- 10.2 cm (4") full range speakers for powerful sound
- Bass Reflex Speaker System delivers a powerful, deeper bass

# Easy to use

- CD to tape synchro-start recording
- Multi-functional LCD display
- On Screen Display for easy navigation
- Handy remote control for extra convenience



# Specifications

### Video Playback

- Playback media: DVD-Video, DVD+R/+RW, picture CD, video CD/SVCD
- Disc playback modes: A-B Repeat, fast backward, fast forward, OSD, pause, PBC, Zoom

# Audio playback

- · Cassette deck technology: mechanical
- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/backward, next/ previous track search, repeat/shuffle/program Number of decks: 1

# **Tuner/Reception/Transmission**

- Antenna: FM antenna
- Tuner bands: FM, MW

### Sound

#### · Sound system: stereo

- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

# Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

# **Audio recording**

- · Recording media: tape
- · Tape recording enhancement: CD synchro start



recording

#### Connectivity

• Audio/Video output: 3.5 mm video out, 3.5mm audio out

#### Convenience

- Display Digits: 7
- Loader type: top
- Display type: LCD display

#### Accessories

- · Cables/Connection: audio/video cable, power cord
- Remote control
- Others: User Manual
- Warranty: Warranty Certificate

#### **Dimensions**

- Gross weight: 4.13 kg
- Packaging depth: 277 mm
- Packaging height: 200 mm
- Packaging width: 450 mm
  Weight: 3.2 kg
- Main unit depth: 238 mm
- Main unit height: 162 mm
- Main unit width: 400 mm

#### Power

Power supply: 100 - 240V AC, 50/60Hz

# Z5738/98

# Highlights

#### 10.2 cm/4" full range speakers 10.2 cm (4") full range speakers for powerful sound

#### **Bass Reflex Speaker System**

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

#### CD synchro-start recording

CD to tape synchro-start recording

#### Multi-functional LCD display Multi-functional LCD display

#### **On Screen Display**

On Screen Display for easy navigation



Issue date 2013-01-26

© 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.1.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 33208 EAN: 87 12581 35835 8

www.philips.com