

Snap & Share

Double action, double fun

The FunCam is the ideal way to get into on-line video-chatting with friends and family or taking VGA-quality snapshots and recording video clips - even away from your PC. It offers superb value-for-money, and with simple installation, you'll be on-line and sharing images and experiences with friends and family in a matter of seconds.



Stay in touch by sharing your experiences

- Video mails via Internet
- Real-time video chatting

High picture quality

- VGA resolution snapshots
- VGA @ 15 fps video quality

Easy to use

- Photo Manager
- LinkExpress
- Microphone in desktop stand
- VLounge control panel



PHILIPS

Commercial Specifications

Picture

- Sensor 1/4" VGA CMOS
- Max. photo resolution VGA (640 x 480)
- Max. video resolution VGA (640 x 480)
- Max. frames per second as a webcam VGA (640x480) up to 15 fps or CIF (320x240) up to 25 fps
- Max. frames per second as a digital camera CIF (320x240) up to 15 fps
- Image format Compressed JPEG
- Video format AVI
- Lens Fixed focus, f=6.2mm
- Focus range 1.1m to infinity
- Exposure Automatic
- Viewfinder Optical
- LCD screen 2 Digit status LCD
- Microphone Built-in in Desktop stand
- Burst mode 3 consecutive frames
- Self-timer 10 s
- Memory Built-in 8 MB SDRAM
- Auto power off After 60 s

Accessories

- Desktop stand with USB 1.1 cable attached
- Neck cord
- Belt clip
- CD-ROM with software and PDF user manual
- Quick installation guide

Connections

- PC Connection USB 1.1

Power supply

- Via USB connection
- Built-in rechargeable Li-Polymer battery

Software

- FunCam driver for Windows
- LinkExpress for automatic image upload from FunCam to PC
- Philips Photo Manager 1.0 for archiving, editing, printing and emailing Snapshots & Video clips
- Philips VRecord for recording video clips with audio when using the FunCam as a webcam
- Acrobat reader 6.0 for reading PDF user manual
- Netmeeting 3.0 for video chatting over the internet
- Works with MSN Messenger and Yahoo! Messenger for video chatting over the internet

PC system requirements

- Operating system Windows 98SE, 2000, ME, XP
- PC system Pentium II or AMD K6-11 or above, 32 MB RAM, 100 MB free HDD, CD or DVD-ROM drive, 1 free USB port, Audio playback capability, Internet connection for video chatting
- Caution PC systems that were upgraded from Windows 95 to Windows 98 may not have USB compatibility

Packaging information

- 12NC 9082 100 02993
- EAN code 87 10895 81949 7
- FunCam (mm) 38 (H) x 83 (W) x 23 (D)
- Desktop stand (mm) 51 (diameter) x 37 (H)
- Weight FunCam excl. desktop stand 41.5 g



Product Highlights

Video mails via Internet

Record a personal video clip and send it as an e-mail attachment to a friend, family or business contact.

Video chatting

On-line video chatting (communication) over a distance.

VGA resolution snapshots

An image taken at VGA resolution means an image of 640 by 480 pixels. An ideal size for e-mails and web pages.

VGA @ 15 fps video quality

VGA (640x480) resolution at 15 frames per second video quality.

LinkExpress

With one button click LinkExpress enables you to transfer all your new images from a digital camera to your PC.

Photo Manager

Philips Photo Manager 1.0 is an easy-to-use software application for archiving, editing, printing and e-mailing your snapshots and video clips.

Microphone in desktop stand

The microphone in the desktop stand allows you to record dialog or to add sound to a video clip recording.

VLounge control panel

VLounge control panel for quickly access your PC camera applications.

