

Philips
DVD home theater system

HDMI 1080p

HTS3164



Simply sounds great

with HDMI 1080p

High quality surround sound and HDMI 1080p upscaling delivered by this system provides superb home entertainment. Playback from USB drives, portable media players and just about any type of disc lets you enjoy movies and music effortlessly.

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- MP3 Link plays music from portable media players

Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- DTS, Dolby Digital and Pro Logic II surround sound
- 12-bit/108MHz video processing for sharp and natural images

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

Easy to set up and use

- Easy-fit™ connectors with color-coding for a simple set-up
- EasyLink to control all HDMI CEC devices via a single remote

PHILIPS

Highlights

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology

that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home

entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, soundbar speaker, Home theater and TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



Specifications

Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg

Packaging dimensions

- Packaging dimensions (W x H x D):
44.6 x 41.7 x 37.8 cm
- Nett weight: 9.765 kg
- Gross weight: 11.485 kg
- Tare weight: 1.72 kg
- EAN: 87 12581 38900 0
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 44.6 x 37.8 x 41.7 cm
- Nett weight: 9.765 kg
- Gross weight: 11.485 kg
- Tare weight: 1.72 kg
- EAN: 87 12581 38900 0
- Number of consumer packagings: 1

Picture/Display

- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan, High Def (720p, 1080i, 1080p)

Sound

- Total Power (RMS): 300 W
- Output power (RMS): 4x37.5W + 2x75W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180-14000 Hz
- Signal to noise ratio: > 60 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo, DTS
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode

Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture Compression Format: JPEG

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- No. of preset Audio Channels: 40
- RDS: Station Name

Connectivity

- Rear Connections: Scart, Component Video output, AUX in, FM Antenna, Easy-Fit Speaker Connectors, Composite video (CVBS) output, HDMI output
- Front / Side connections: Hi-Speed USB, MP3 Line-in

Power

- Power supply: 230V, 50Hz
- Standby power consumption: < 1 W

Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 8 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45-150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, Scart Cable, FM antenna, Quick start guide, User Manual, World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 360 x 58 x 332 mm
- Set weight: 2.8 kg
- Surround Speaker dimensions (W x H x D):
103 x 203 x 71 mm
- Surround speaker Weight: 0.45 kg
- Center speaker dimensions (W x H x D):
244 x 105 x 74 mm
- Center Speaker Weight: 0.78 kg
- Subwoofer dimensions (W x H x D):
123 x 310 x 369 mm
- Subwoofer Weight: 3.85 kg
- Packaging dimensions (W x H x D):
446 x 417 x 378 mm
- Weight incl. Packaging: 11.5 kg



Issue date 2017-04-04

Version: 2.0.9

12 NC: 8670 000 36281
EAN: 87 12581 38900 0

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com