



Philips  
wireless portable speaker

Bluetooth®  
White

BT51W

## Make room to dance

Take your tunes out with the Bluetooth speaker that fits in your pocket. This tiny speaker gives you six hours play time and crisp sound, even at maximum volume. The wireless range is 10 m. Plenty of room to dance across the room.

### Always ready to go

- Really light. Weighs just 90 g
- Really small. 6.1x6.1x7.6 cm
- Up to 10 m wireless range

### Easy to pair. Easy to charge.

- Bluetooth is ready to pair with power-on
- USB charging. Micro USB cable included

### Tiny speaker. Crisp sound out loud.

- 1.5" full-range speaker. Crisp, clear sound
- 5 hours play time
- Anti-clipping function. Turn it up without distortion

# PHILIPS

wireless portable speaker  
Bluetooth® White

# Specifications

## Sound

- Output power (RMS): 2W
- Sound System: Mono

## Design and finishing

- Color: White

## Connectivity

- Bluetooth profiles: A2DP, AVRCP, HFP
- Bluetooth range: Line of sight, 10M or 30FT

## Compatibility

- other Bluetooth-enabled device
- work with: up to iOS 10.2, Bluetooth 4.2 or below

## Power

- Battery type: lithium polymer (built-in)
- Operating time on battery: 5 hour(s)

## Accessories

- Included accessories: Quick install guide, World Wide Warranty leaflet
- Cable: USB charging cable

## Dimensions

- Product dimensions (WxDxH): 6.1 x 6.1 x 7.6
- Weight incl. Packaging: 0.18 kg
- Packaging dimensions (WxDxH): 8.1 x 9.5 x 11.3 cm
- Product weight: 0.135 kg

BT51W/00

# Highlights

## Tiny speaker. Crisp sound.

Weighing just 90 g, you'll barely notice you're carrying this tiny speaker. The 1.5" full-range driver delivers crisp, clear sound even when you turn the volume up.

## 5 hrs play time. USB charging.

The battery gives you 5 hours play time from a full charge. Charging takes less than 3 hours, and is easy via the included micro USB cable.

## Bluetooth connectivity

Pairing with your Bluetooth device is simple. Just power on the speaker and it's ready to pair. The wireless range is 10 m.

## Anti-clipping function

Anti-Clipping lets you play music louder and keeps its high quality, even when the battery is low. It accepts a range of input signals, from 300mV to 1000mV and keeps your speakers safe from damage by distortion. This built-in function monitors the musical signal as it goes through the amplifier and keeps peaks within the amplifier's range, preventing the audio distortion caused by clipping without affecting loudness. A portable speaker's ability to reproduce musical peaks decreases along with battery power, yet anti-clipping reduces peaks caused by low battery, keeping music distortion free.

## Really light. Weighs just 90 g

Really light. Weighs just 90 g

## Really small. 6.1x6.1x7.6 cm

Really small. 6.1x6.1x7.6 cm

## Up to 10 m wireless range

Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can enjoy your favorite music, sound from video or game wireless on this speaker easily.

## USB charging.

Micro USB cable included



Issue date 2024-03-24

Version: 7.1.3

EAN: 69 51613 99572 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)